

# User guide

Gizmo Watch 3

**verizon**

# Table of Contents

<b>What You'll Find in the Box .....</b>	<b>5</b>
<b>Gizmo Watch 3 Overview .....</b>	<b>6</b>
Front .....	6
Back.....	7
<b>Charging Your GizmoWatch.....</b>	<b>8</b>
<b>Cleaning the Charging Port.....</b>	<b>9</b>
<b>Turning Your GizmoWatch On and Off.....</b>	<b>10</b>
<b>Pairing Your GizmoWatch to the GizmoHub App.....</b>	<b>11</b>
<b>Register as Primary Guardian and Add Your Child's Profile in the GizmoHub App.....</b>	<b>13</b>
<b>Adding Contacts .....</b>	<b>15</b>
<b>The GizmoHub App .....</b>	<b>20</b>
Dashboard.....	20
The GizmoHub Control Panel .....	22
Adding Another Child.....	25
Adding Another Gizmo .....	29
Calling your Gizmo from GizmoHub.....	30
Messaging.....	31
Checking Your GizmoWatch's Location.....	33
Setting Alerts and Location Checks .....	34
Viewing Notifications .....	42
Using the Step Counter .....	43

Managing Your Child's To-Do List .....	45
School Mode.....	47
Managing Gizmo Settings.....	48
Make Gizmo's Alarm Ring .....	50
Reset Your GizmoWatch .....	51
Setting Up a PIN for Security.....	52
About the GizmoHub App.....	54
<b>Using GizmoWatch .....</b>	<b>55</b>
Wearing the GizmoWatch .....	55
Swapping the Loop Strap .....	56
Replacing the Wristband.....	58
Home Screen.....	59
Making and Receiving Calls .....	60
Sending and Receiving Messages.....	62
Changing a Contact's Avatar .....	65
Adding a Gizmo buddy.....	67
Configuring GizmoWatch Settings.....	68
Other Features.....	74
<b>Safety Information.....</b>	<b>90</b>
Watch Water Resistance Information.....	90
Important Safety Precautions.....	91
Additional Safety Guidelines .....	93
Caring for Your Device.....	94
Federal Communication Commission Interference Statement .....	96
RF Exposure Information (SAR) .....	97
WEEE.....	99

<b>Warranty Information.....</b>	<b>100</b>
Warranty Period .....	100
Limited Warranty Statement .....	100
Disclaimer of Warranties; Exclusion of Liability .....	101
IEEE 1725 Battery Safety Statement.....	103

## **What You'll Find in the Box**

Make sure the following items are included in the GizmoWatch box:

- Gizmo Watch 3
- Loop straps x 3
- Charging Cord
- Quick Reference Guide
- Product Safety & Warranty Brochure
- Important Consumer Safety Information

NOTE: If any items is missing, please contact the store where you bought it.

# Gizmo Watch 3 Overview

## Front



## Back



NOTE: Devices, software and apps are constantly evolving. The images, icons and features mentioned in this document are for reference only.

## Charging Your GizmoWatch

Before you start, charge your watch completely.

1. Line up the gold pins on the charging cord with the charging contacts on the back of the watch. The watch and charging cord are magnetized and should connect without effort.



2. Plug the other end of the cord into the charging adapter and plug the adapter into an electrical outlet.

**WARNING:** Use only approved chargers with your device. Incompatible chargers or tampering with the charging contacts could damage your device and void the warranty.



## Cleaning the Charging Port

Power off the Gizmo Watch 3 and unplug the charger from the power source.

Ensure the connector plates and magnetic charging points are clean.



If necessary, clean the charging points with a cotton swab, microfiber cloth or an alcohol wipe cloth to remove dirt and debris.

**CAUTION:** Don't attempt to charge until the connection points are fully dry.



# Turning Your GizmoWatch On and Off


## Turning your watch on

- Press and hold the **Power**  button until the screen lights up.




## Turning your watch off


- Press and hold the **Power**  button until you see “Do you want to turn off?” on the screen. Then tap  to turn off your watch.



# Pairing Your GizmoWatch to the GizmoHub App

Make sure you're in an area with a strong wireless signal.


1. Your GizmoWatch should start activating automatically the first time you turn it on.
2. When the watch instructs you to download the GizmoHub app, first decide who you want to be Primary Guardian (the person who completes the registration and sets up the GizmoWatch).
3. Then download and install the GizmoHub app on that person's smartphone from the Google Play Store (Android OS 4.0 or higher) or the Apple App Store (iOS 7 or higher). Data usage may apply for app download and use.
4. Once you download the app, tap  on the bottom of the watch screen to continue.




- When your GizmoWatch has been activated successfully, it will announce and show the mobile number.



- Follow the instructions in the app and on your watch to pair your GizmoWatch, by scanning the QR code with your phone's camera or by entering the GizmoWatch's mobile number into the app.

NOTE: Be sure to tap  on the screen under **Tap to finish pairing**.



# Register as Primary Guardian and Add Your Child's Profile in the GizmoHub App


Follow the instructions in the app to:

- Accept the Gizmo Privacy Policy and register as Primary Guardian



- Add your child's profile

< **Add a child**



Tap to add image

Child's first name

Birth date Oct 30, 2016

July	27	2013
August	28	2014
September	29	2015
<b>October</b>	<b>30</b>	<b>2016</b>
November	31	2017
December	1	2018
January	2	2019

Your relationship to child

**Save**

## Adding Contacts

The Primary Guardian can use the GizmoHub app to register up to 19 additional phone numbers as Guardians, Caregivers, Gizmo buddies, or Calling contact.\* All contacts can call the GizmoWatch from their registered phone number and receive calls from it. Gizmo buddies can text or call the GizmoWatch from their Gizmo devices. Only Guardians and Caregivers can use the app.

Contact Types	Guardians	Caregivers	Gizmo buddy	Calling contact
Call & get calls from Gizmo	✓	✓	✓	✓
Text with Gizmo	✓	✓	✓	
Locate Gizmo	✓	✓		
Get Time, Location & other alerts	✓	✓		
Turn Gizmo off & change settings	✓			
Add & manage contacts	✓			

To view GizmoWatch's contact list in the GizmoHub app, scroll down to **Contacts** in the child's profile. To view the contacts on the watch, swipe left from the main screen.

NOTE: \*You will be notified on your GizmoHub app when you have reached the maximum number of contacts.


## Adding Contacts


Gizmo Watch 3 supports up to 20 contacts, including the primary guardian. To add contacts:


1. From your GizmoHub app, tap **More > Manage contacts**.

NOTE: You can also add contacts by tapping **Kids**, and then “Add a contact” button.

2. Tap  at the top right of the screen.



3. Tap  to add a contact from your phone or enter the contact's information in each field. Then tap **Next**.





4. Select the Permission Level you want to assign to the contact and tap **Save**.

Permissions for Mmm

PoneB's GizmoWatch

Select a permission level so Mmm can interact with PoneB's GizmoWatch.

Permission Level

No permission

Guardian

Caregiver

Calling contact

No permission

**NOTE:**

- The new contact will also appear in the Gizmo's Contact List.
- If you give the contact a higher Permission Level, you will be able to give the contact more information.

Permission Level

Caregiver

**Time & location alerts**

Scheduled (time-based), Check-ins, Arrived at Saved Location, and Left Saved Location


**Activity Alerts**


Steps and To-Dos

**Auto-answer calls**


If child doesn't answer after 10 seconds, Gizmo will put the call through automatically.

## Deleting Contacts


1. From your GizmoHub app, tap **More** > **Manage contacts**.
2. Tap  at the top right.



3. Tap  next to the contact you want to remove.



4. You are prompted to confirm deletion. Tap **Continue** and then tap **Delete Contact**.



**NOTE:** Deleting primary guardian will cause the GizmoWatch to reset. All contacts will be deleted and must be added again by a new primary guardian.


## **The GizmoHub App**

Guardians and caregivers can use GizmoHub to locate and communicate with the GizmoWatch. Guardians can also use GizmoHub to manage contacts and settings.

### **Dashboard**

From your GizmoHub dashboard, you can call and chat with your child, see the Gizmo's location on the map, and see your notifications, your call log, your child's step counter and to-do list, as well as your Gizmo's battery status.



If you have more than one child, swipe left or right to see each child's dashboard.




## The GizmoHub Control Panel

At the bottom of the dashboard, you'll find the Control Panel. Use the Control Panel to navigate to different parts of the GizmoHub app.

- Tap **Dashboard** to return to the dashboard.
- Tap **Kids** to access your child's full profile. If you have more than one child, swipe left or right to see more profiles. From here, you can manage your child's location alerts, contacts, to-do list and more.




- Tap **Messages** to send messages to and receive messages from the GizmoWatch.



- Tap **More** to see other options. From here, you can:
  - Manage your profile
  - Manage all your Gizmo devices and add new Gizmos
  - Manage your contacts
  - Add a child
  - Manage security PIN

- Manage analytics
- Read FAQs
- Turn the Guide feature on and off
- Read the Terms & privacy info
- See the GizmoHub About screen
- Sign out from GizmoHub
- Provide feedback on GizmoHub app







## Adding Another Child

The GizmoHub app lets you manage all your Gizmo devices in one place. To add a Gizmo for another child, start by adding the child.

1. From a Guardian's GizmoHub **Dashboard**, tap **More > Add a child**.



2. Tap  to change the profile picture. Then enter the child's information, such as name, birth date, and your relationship to the child.
3. Tap **Save**.



Tap to add image

Child's first name

Emma 4/20

Birth date Oct 10, 2019


July	7	2016
August	8	2017
September	9	2018
October	10	2019
November	11	2020
December	12	2021
January	13	2022

Your relationship to child

Mama

Save

4. Make sure the Gizmo you want to add to this child's profile is fully charged and activated. When you're ready, tap **Add a Gizmo**.
5. Tap **Pair Gizmo** and choose how you want to pair the GizmoWatch with the GizmoHub app.




- Select **Scan QR code** to automatically pair the watch by using the QR code.





- Select **Don't see a QR code?** to manually pair the watch by entering its phone number. After entering the number, tap **Next**.



NOTE: To obtain the phone number on the GizmoWatch, see “Managing Gizmo Settings”.

6. Once the GizmoWatch has successfully paired with the GizmoHub app, tap  (on the watch) to complete the setup.



NOTE: To edit an existing child profile, swipe to that child's profile on the **Dashboard**. Then tap **Kids** > . From here, you can also tap **Remove child** to delete the child's profile.




## Adding Another Gizmo



You can link multiple Gizmos to the GizmoHub app. There are several ways to do this:

- From the **Control Panel**, tap **More** > **Manage devices** > **Add a Gizmo**.
- If you're adding a Gizmo for a child who doesn't have a profile yet, you can add the child and then add the Gizmo. (See "Adding Another Child").
- If you want to add the device to an existing child's profile: from the **Dashboard**, either find the child's profile or tap **Kids** in the **Control Panel** and find the profile there. Then tap **Add a Gizmo**.

Then follow the onscreen instructions.

## Calling your Gizmo from GizmoHub

From the GizmoHub **Dashboard**, swipe left or right to find the child you want to call. Then tap  to call the GizmoWatch.





**NOTE:** When the **Auto-answer calls** setting is turned on, GizmoWatch will automatically answer the call in 10 seconds. Auto-answered calls automatically end after 1 minute.

## Messaging

### Sending and receiving messages from the GizmoWatch

Kids can use the GizmoWatch to exchange text messages with Guardians and Caregivers (using GizmoHub), and Gizmo buddies (using their Gizmo devices).


1. From the **Control Panel**, tap **Messages**.
2. Type your message and then tap . You can enter up to 120 characters.




NOTE: Besides sending text, you can also send an image as an attachment or send the message with an emoji.

## Messaging Options

From **Messages**, tap **:** to select one of the available options:



- Tap **Edit child's messages** to change any of the quick messages your child can send.





- Tap **Delete all messages** to delete the conversation.

NOTE: GizmoWatch can send only one emoji per message.








## Checking Your GizmoWatch's Location

Tap **Dashboard** and swipe to select the child you want to locate. Tap the map and then tap  to locate your Gizmo.



In the map view, you can also do the following:

- Tap on the map to view it full screen. Tap again to return to dashboard view.
- Tap  to turn on real-time tracking.
- Tap  to turn on satellite view (default is street view).
- Tap  and then select a date to view the history of locations for that date.
- Tap the current location or a location from history and tap  and  to select **Add to saved locations** or **Directions** to the location.
- Pinch in or out any area of the map to zoom in or out.

## Setting Alerts and Location Checks


Guardians and Caregivers can use the GizmoHub app to set Alerts and Location Checks to keep track of the Gizmo's location.

To start, tap **Kids** in the **Control Panel** and swipe to the child's profile.


### Naming places

You can name places your child visits often (e.g., "home", "school" or "aunt's house") so you can identify it by name instead of a GPS address.

1. Tap **Add a location**. Enter the address and tap **Next** to continue.



## 2. Enter the location name and tap **Next**.



### Using alerts to show when the GizmoWatch is at a place you have set

You can choose between two kinds of alerts.


- **Location-based alerts** notify you when your child's Gizmo moves into or out of a specific area. For example, if your child is supposed to be at the library on Wednesday between 3 and 5 PM, a location-based alert can send you notifications when your child's Gizmo arrives at

or leaves the library.

- **Time-based alerts** notify you with an update on your child's Gizmo location at a specific time or time range.

To add an alert:

1. From the child's profile, tap **Add a location alert**.
2. Select the method you want to use to track the Gizmo.




NOTE:

- You can create up to 5 location-based and 20 time-based notifications.

## Location-based

1. If a window pops up asking to share a location, tap **Allow**.
2. Enter or select a location in the **Add Location** field or drag your child's location pin to a desired spot on the map.

3. Drag the circle around the location pin to your desired size. You will receive an alert any time your Gizmo crosses the circle.
4. Give this location a name (e.g., aunt's house) and tap **Next**.



5. Set the time range and the day for notification. Then tap **Save**.

< Location-based Alert

Set time range

Start 2:20 PM ^

11	17
12	18
1	19 AM
2	20 PM
3	21
4	22
5	23

End 3:20 PM v

Set your weekly schedule

Mo  Tu  We  Th  Fr  Sa  Su

Save

Dashboard Kids Messages More



< Location-based Alert

Start 2:20 PM ^

11	17
12	18
1	19 AM
2	20 PM
3	21
4	22
5	23

End 3:20 PM ^

12	17
1	18
2	19 AM
3	20 PM
4	21
5	22
6	23

Set your weekly schedule


Mo  Tu  We  Th  Fr  Sa  Su

Save


Dashboard Kids Messages More

## Time-based


1. Tap **Time-based**.
2. Select when you want to be notified.
  - Tap **Specific Time** to set the time and the day. Then tap **Save**.



- Select **Time Range** to select a start time and end time to get alerted of your Gizmo's location. Then select the day(s) for the alert and tap **Next**.



Adjust the **Frequency Setting** slider to select how often you want to be alerted of your child's location.



**NOTE:** More frequent checks will affect the Gizmo's battery life.



## **About Location Information and Accuracy**


Your GizmoWatch's location will usually be shown as a place name or an address. When a place name or address can't be determined, GPS coordinates will be shown.


Location is usually provided by Assisted GPS for fast positioning. If unsuccessful, the GizmoHub app will attempt to locate the GizmoWatch using a different method.

- When the GizmoWatch is located in a place where GPS or Wi-Fi isn't available (or if the GizmoWatch is turned off), the GizmoHub app won't be able to show location information.
- Location information may be unavailable, inaccurate or incomplete, depending on your Gizmo's surroundings.
- It may take up to 3 minutes to get your Gizmo's location information.
- A location error of up to several miles can occur.
- If the GizmoWatch is indoors, the location can be inaccurate or unavailable.

NOTE: The Wi-Fi connection is reception only, to assist with location. There's no Wi-Fi signal transmission.

## Viewing Notifications

To see notifications about Gizmo activity, go to your child's **Dashboard** or profile and tap  to view all notifications.




## Using the Step Counter

On the Dashboard, you can turn the step counter on and off and set a step goal for your child.

### Turning on the step counter


On the **Dashboard**, swipe to select a child. In the **Steps** card, tap **Set step goal**. Then slide the switch to the right to turn it on.



## Setting a step goal

Once the step counter is on, you can set a goal (number of steps), request a daily notification, and add a reward for reaching the goal. Then tap **Save** to save the settings.


The daily steps goal will appear on the Dashboard and in your child's profile.



### NOTE:

- The number of steps will also appear on your child's watch, but not the rewards. See "Viewing the step count".


- You can also edit the goal from your child's profile. In the **Control Panel**, tap **Kids**. Then swipe to find the profile you want to update.



## Managing Your Child's To-Do List

You can create a to-do list to remind your child of important tasks.



- From your child's **Dashboard**, tap **Add a to-do** in the **To-do list** card. Then tap **Add to-do**.



- Slide the switch to turn on the To-do.




- Enter the task name, set the duration (if there is one) and how often you want it to be done (Recurrence).
- Enter the reward for completing the task. Then tap **Save**.



## NOTE:

- The To-do list and the reward will appear on your child's watch. See "Viewing tasks".
- You can also edit the current task or add a new task from your child's profile. In the **Control Panel**, tap **Kids**. Then swipe to find the profile you want to update.



## School Mode



While your child is at school, you can switch Gizmo to **School mode** to restrict Gizmo to emergency calling only. The **School mode** can be turned on either temporarily or based on a schedule.

- **Turning on the School mode temporarily:**  
From your child's **Dashboard**, slide the **School mode** switch to the right to turn on the mode.




- **Scheduled School mode:**
  1. From the **Control Panel**, tap **More > Manage devices** and select the GizmoWatch.

2. Tap **Schedule school mode** and then follow the screen instructions to set the schedule.



## Managing Gizmo Settings

You can manage your GizmoWatch's settings from the GizmoHub app. From the **Control Panel**, tap **More** > **Manage devices** and select the GizmoWatch.





From here, you can see information on battery life and the watch's name, mobile number, and software version. You can control settings for:

- School mode
- Volume
- Auto-answer calls
- Ringtone
- Touch sound
- Theme



- Resolution
- Check for device software update
- Sync device settings
- Gizmo power settings
- Turn off Gizmo
- Delete Gizmo




**NOTE:** If you turn off Gizmo, it cannot be turned back on from the app.


## Make Gizmo's Alarm Ring

If you can't find your child's Gizmo, you can use the GizmoHub app to make the alarm ring.

1. From the child's profile, tap **Find Gizmo**.



2. The app will automatically find and ring your child's watch.






NOTE: To stop the ringing, tap the watch's power button.

## Reset Your GizmoWatch

1. From the **Control Panel**, tap **More > Manage devices** and select the GizmoWatch.
2. Tap **Delete Gizmo** to reset your GizmoWatch to its factory settings.




NOTE: You can also reset your GizmoWatch to its factory settings by placing it on the charging cord, and pressing the **Power**  button 4 times. Then swipe  to the right to reset the device.



## Setting Up a PIN for Security

If you didn't create a security PIN during setup, you can still create one so others can't open the GizmoHub app on your smartphone.

1. From the GizmoHub **Dashboard**, tap **More > Manage security PIN**.



2. Enter a 4-digit PIN.
3. Enter the same 4-digit PIN and tap **SAVE**.


NOTE: To change the PIN, you must first remove the existing PIN by entering your current PIN to the **More > Manage security PIN > Change security PIN > Enter your current 4-digit security PIN** field. Then create a new PIN and enter it to **Now enter your new 4-digit security PIN** and **Re-enter your new 4-digit security PIN** fields. Tap **Finished** to complete the procedure. If you enter your PIN incorrectly 5 times, the GizmoHub app will be reset. To continue using the GizmoHub app after it is reset, you will need to log back into your account.

## FAQs

Tap **FAQs** to find answers to the most commonly asked questions about Gizmo devices.

## Turn On Guide


Tap **Turn on guide** to show tips about various functions.



NOTE: To hide the tips, go to **More > Turn off guide**.

## About the GizmoHub App

Tap **About** to view the version number of GizmoHub app, operating system, Analytics, and Activation.



## Share Feedback

Tap **Feedback** to email Gizmo Support directly from your smartphone.

# Using GizmoWatch

## Wearing the GizmoWatch

The GizmoWatch should fit snugly, but not too tightly, around your child's wrist.

1. Wrap the wristband around your child's wrist.
2. Slide the wristband through the buckle and adjust for comfort (A).



3. Insert the pin on the underside of the buckle into one of the holes on the wristband (B).



- Slide the wristband through the loop (C).



## Swapping the Loop Strap

NOTE: Additional loop straps are supplied in three different colors.

- Pull the release knob all the way in the opposite direction (A).






2. Detach the wristband from your GizmoWatch (B).



3. Remove the loop strap from the wristband (C).



4. Replace the loop strap (D).




## Replacing the Wristband

1. Insert the pin (the opposite side of the release knob) into the pin hole on your GizmoWatch (**A**).




2. Pull the release knob all the way in the opposite direction and align the other end of the pin with the hole on your GizmoWatch (**B**). Release the knob to lock the wristband in place.



## Home Screen

Your GizmoWatch has a touch screen. Just swipe left, right, up or down to switch pages:

- Watch Screen
- Contacts
- Apps
- Settings




**NOTE:** You can access the **Notifications** page by swiping down from the **Watch screen**.





# Making and Receiving Calls


## Making a call

1. From the **Watch screen**, swipe left to open the **Contact List**. Then select the contact you want to call.



2. Tap  to make an audio call or tap  to make a video call.





To end the call, tap .



**NOTE:** Your GizmoWatch can only make and receive calls from phone numbers on your child's Contact List. These numbers may be for mobile phones, landlines, and other Gizmo devices. You can manage the Contact List in the GizmoHub app.

## Receiving a call

When someone from your child's contact list calls the GizmoWatch, it will ring and the caller name will be shown on the screen.

- To answer the call, tap .
- To reject the call, tap .



- To end the call, tap .

TIP: Tap  to adjust the volume level during the call or tap  to mute the call.

NOTE:

- Verizon sets a time-duration limit on video calls to prevent the device from overheating. A video call on the GizmoWatch can last up to 3 minutes. A video call ends automatically when a call's duration passes its allowable 3-minute duration limit.
- A notification appears on screen for any missed call.





# Sending and Receiving Messages



## Sending a message

1. From the **Watch screen**, swipe left to open the **Contact List**. Then select the contact you want to message.





2. Tap  to create a new message. Then:





- To create a voice message, tap . Then tap  to start recording a voice message.




- To record a video, tap . Then tap  to start recording a video.



- To capture a selfie, tap . Then tap  to take a photo of yourself.




- To choose from a list of pre-written messages, tap  and select the message screen.



- To choose an emoji, tap 😊. Then select the desired emoji.



- To send recorded photo/video from the gallery, tap 📷. Then select the desired photo/video.



3. Tap 📩 to send.


NOTE:

- GizmoWatch can only send one emoji per message.
- You can also send a message from the Apps screen. Refer to page 74.



## Receiving a message


When the GizmoWatch receives a new message, it will appear on the **Watch screen**. Tap to read the message.



NOTE: Your GizmoWatch can only receive messages from contacts with the GizmoHub app or from other Gizmo devices if the sender is a Gizmo buddy.

## Changing a Contact's Avatar

You can change a contact's avatar.


1. From the **Watch screen**, swipe left to open the **Contact List**. Then tap the contact whose picture you want to change and tap .




2. Tap to select a new avatar.




## Checking In (Send current location)

Children can send their current location to the GizmoHub app by swiping down from the **Watch screen** and then swiping  right.



Guardians and Caregivers will receive a message displaying the GizmoWatch's location.





## Adding a Gizmo buddy

NOTE: All Gizmo Watch models can have Gizmo buddies added in the GizmoHub app, but only Gizmo Watch 3 can find another nearby Gizmo Watch 3 to make a Gizmo buddy request.


1. Have both watches turned on and in the same room.

NOTE: Both buddies must do steps 2-4 at the same time.

2. From the **Watch screen**, swipe left to open the **Contact List**.
3. Tap **+** to add a new buddy.
4. When Gizmo Watch 3 finds the buddy, tap their icon.




5. A buddy request will be sent to the GizmoHub app for each buddy's guardian to approve.



## Configuring GizmoWatch Settings

### Adjusting the volume


Swipe right from the **Watch screen** until you see the **Settings** screen.

Tap  to enter the **Volume** screen. Then drag the slider to adjust the volume level.



### Changing the watch face

Swipe right from the **Watch screen** until you see the **Settings** screen.


Tap  to enter the **Set Watch faces** screen. Then select the desired watch face and tap on it.



## Pairing with Bluetooth device

Swipe right from the **Watch screen** until you see the **Settings** screen.

Tap  to enter the **Paired devices** screen. Then tap  to pair with another GizmoWatch.



## Changing the theme


Swipe right from the **Watch screen** until you see the **Settings** screen.

Tap  to enter the **Themes** screen. Then select the desired theme.



## Changing the ringtone


Swipe right from the **Watch screen** until you see the **Settings** screen.


Swipe up and tap  to enter the **Ringtones** screen. Then select the desired ringtone and tap on it.



## Adjusting the screen brightness


Swipe right from the **Watch screen** until you see the **Settings** screen.

Swipe up and tap  to enter the **Brightness** screen. Then drag the slider to increase or decrease the brightness level.



## Enabling Tap to Wake function


Swipe right from the **Watch screen** until you see the **Settings** screen.


Swipe up and tap  to enter the **Display wake up** screen. Then tap the screen to enable or disable the function.



## Configuring the screen timeout


Swipe right from the **Watch screen** until you see the **Settings** screen.


Swipe up and tap  to enter the **Screen timeout** screen. Then select the length of time you want the screen to display before it times out, and tap on it to confirm the selection.



## Enabling the vibration function


Swipe right from the **Watch screen** until you see the **Settings** screen.

Swipe up and tap  to enter the **Vibration** screen. Then tap the screen to enable/disable the function.



## Viewing your personal information

Swipe right from the **Watch screen** until you see the **Settings** screen.


Swipe up and tap  to enter the **Medical ID** screen. It displays your name, date of birth, height, weight, emergency contact, notes, medication, and blood type.





## Viewing GizmoWatch information

Swipe right from the **Watch screen** until you see the **Settings** screen.

Swipe up and tap  to enter the **About Gizmo** screen. It displays your GizmoWatch's model number, mobile number, IMEI, ICCID, software version, and the total lifetime calls.




## Other Features

### Sending messages

Swipe right from the **Watch screen** until you see the **Apps** screen.



Tap  to enter the **Messages** screen.



NOTE: For more information on sending messages, refer to page 62.

### Taking a selfie



Swipe right from the **Watch screen** until you see the **Apps** screen.


Tap  to enter the **Camera** screen. Then tap  to take a selfie.




## Recording a video

Swipe right from the **Watch** screen until you see the **Apps** screen.

Tap  to enter the **Camera** screen. Then tap  to switch to video mode.




Tap  to start recording the video (up to 20 seconds).




To manually stop recording the video, tap .

## Viewing the weather

Swipe right from the **Watch screen** until you see the **Apps** screen.


Tap  to enter the **Weather** screen. The weather at your current location will be shown on the screen.



Swipe right to view the three day forecast.

## Viewing the step count


Swipe right from the **Watch screen** until you see the **Apps** screen.

Tap  to enter the **Steps** screen. The number of steps and the set goal will be shown on the screen.





## Playing Tic Tac Toe

Swipe right from the **Watch** screen until you see the **Apps** screen.


Swipe up and tap  to enter the **Games** screen. Then select **Tic Tac Toe** to start the game.



Select a character. Then start the game by tapping on an empty square to put your mark.





NOTE: Below message will appear on the screen when you win.



## Playing Puzzle

Swipe right from the **Watch** screen until you see the **Apps** screen.

Swipe up and tap  to enter the **Games** screen. Then select **Puzzle** > **Start puzzle** to start the game.



Drag the blocks to move them.





TIP: When you get stuck, tap **Menu** to restart the game, switch to another puzzle, or view the complete puzzle board.



## Playing Gizmo Says

Swipe right from the **Watch** screen until you see the **Apps** screen.

Swipe up and tap  to enter the **Games** screen. Then select **Gizmo Says > Start playing** to start the game.




Watch and listen carefully to what Gizmo says. When it's your turn, tap to repeat the pattern.




## Changing your voice


Swipe right from the **Watch screen** until you see the **Apps** screen.


Swipe up and tap  to enter the **Audio message** screen.



Tap  to start recording a message (up to 20 seconds).




TIP: To manually stop the recording, tap .

After the recording ends, swipe left or right to play your recording as different characters. Then tap  to send a voice message to the selected contact.



## Viewing tasks



Swipe right from the **Watch** screen until you see the **Apps** screen.

Swipe up and tap  to enter the **To-do** screen. The incomplete task(s) will be shown on the screen.



A reminder will pop up on the screen to let you know a scheduled task event is about to start.





- Tap  to mark that you have started performing the assigned task.
- Tap  to pause performing the task.





## Using the stopwatch



Swipe right from the **Watch screen** until you see the **Apps** screen.

Swipe up and tap  to enter the **Stopwatch** screen.



Tap  to start the stopwatch.



When the stopwatch is running, tap  to pause the stopwatch.






When the stopwatch is paused, you can:

- Tap  to resume the stopwatch.
- Tap  to reset the stopwatch.

## Playing the Jumps game

Swipe right from the **Watch screen** until you see the **Apps** screen.


Swipe up and tap  to enter the **Jumps** screen. Then tap  to start the jump counter.



When you reach the targeted number of jumps, you can continue to the next level.

## Adding an Alarm

Swipe right from the **Watch screen** until you see the **Apps** screen.


Swipe up and tap  to enter the **Alarm** screen.

a. Tap  to add an alarm.




b. Set the time and tap ✓.

c. Select the repeat schedule and tap ✓.



d. Select the alarm sound and tap ✓.


e. Slide  to the right to enable the alarm.





Tap + to add another alarm.



## Managing the Alarm


Swipe right from the **Watch screen** until you see the **Apps** screen.

Swipe up and tap  to enter the **Alarm** screen. Then select the alarm that you manage.

- To edit the alarm, tap . Make your changes and tap  to save.




- To delete the alarm, tap . Tap  to confirm deletion.



## Using the calculator


Swipe right from the **Watch** screen until you see the **Apps** screen.


Swipe up and tap  to enter the **Calculator** screen. Then perform mathematical calculations.




## Using the timer


Swipe right from the **Watch** screen until you see the **Apps** screen.

Swipe up and tap  to enter the **Timer** screen. Set the timer.





Tap  to start the timer.



When the timer is running, tap  to pause the timer.





When the timer is paused, you can:


- Tap  to resume the timer.
- Tap  to reset the timer.

## Managing photos/videos in the gallery

Swipe right from the **Watch** screen until you see the **Apps** screen.

Swipe up and tap  to enter the **Gallery** screen.









NOTE: You can also access the gallery by tapping  on the Camera screen.






Swipe the screen up or down to browse the gallery. Then select the desired photo/video to view.



- Tap  to delete the photo/video. When prompted, tap  to keep the photo/video or tap  to confirm deletion.
- Tap  to send the photo/video to a contact in the **Contact List**.
- Tap  to play the video.





- To adjust the volume level, tap .
- To pause during playback, tap the screen and tap . To resume, tap .





## Playing fun sounds

Swipe right from the **Watch screen** until you see the **Apps** screen.

Swipe up and tap  to enter the **Fun sounds** screen. Then select the desired theme and tap one of the  icons to play fun sounds.



# Safety Information

This section outlines the safety precautions associated with using the device.

## Watch Water Resistance Information

Your device has been certified with an IP68 rating. It is splash and water resistant, but submerging your watch is not recommended.

To maintain water resistant performance of your device, observe the following:

- Do not submerge your device in water for extended periods of time (more than 60 minutes).
- Do not immerse your device in:
  - water deeper than 1.5 meter (about 3.28 feet)
  - any other liquid chemicals other than water
  - salt water, such as sea water
  - warm water
- Do not wear your device while swimming or snorkeling.
- Do not place your device directly on sand or mud.
- Do not use your device in places where it may be exposed to high pressure water such as ocean waves or waterfalls.
- Do not drop your device or subject it to shock. Doing so might damage the main unit, allowing water to get inside your device.

## **Important Safety Precautions**

Please read the safety and operation instructions before using your device or any accessories that came with it. Retain these instructions for future use.

- Do not set up your device or use it while driving. Using your device while driving could put you and others at greater risk of an accident causing serious injury, death, and property loss. You are responsible for knowing and obeying the laws and regulations regarding the use of wireless devices in the areas where you drive.
- Do not use your device or accessories near water (for example, near a bathtub or a sink, in a wet basement, or near a swimming pool) or spill liquid of any kind on your device or accessories, as this might cause a short circuit, a fire, or an electric shock which could cause serious injury, death and property loss.
- Do not use your device in the presence of gas fumes, as it presents a risk of fire or explosion.
- Do not use or store your device in extreme temperatures, as your device might overheat and may present a burn and fire risk and cease to function.
- Do not dispose of your device in a fire, as this might cause an explosion, resulting in serious injury, death and property loss.
- Federal Aviation Administration (FAA) and Federal Communications Commission (FCC) regulations prohibit using the radio of wireless devices while in the air. Turn off all wireless connections on your device before boarding an aircraft. Using your device on an aircraft might affect aircraft instrumentation, communication, and

performance; might disrupt the network; might otherwise be dangerous to the operation of the aircraft, its crew, and its passengers; and might be illegal.

- Do not disassemble your device. Your device contains small parts that might be a choking hazard.
- Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment might not be shielded against the RF signals from your device. Keep your device away from medical devices, including pacemakers and hearing aids, as they might malfunction and cause serious injury or death to you and others.
- Turn off all wireless connections on your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.
- Certain jurisdictions might prohibit or restrict your use of certain features on your device.

## **Additional Safety Guidelines**

### **About Charging**

- Use only the charger supplied with your device. Use of another type of charger will result in malfunction and/or danger.
- Do not use the charger in a high moisture environment. Never touch the charger when your hands or feet are wet.
- Allow adequate ventilation around the charger when using it to operate the device or charge the battery. Do not cover the charger with paper or other objects that will reduce cooling. Do not use the charger while it is inside a carrying case.
- Connect the charger to a proper power source. The voltage requirements are found on the product case and/or packaging.
- Do not use the charger if the cord becomes damaged.
- Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is damaged or exposed to excess moisture.

## About the Battery

This unit contains a non-replaceable internal lithium-ion battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, puncture or dispose of in fire or water.

### **Important instructions (for service personnel only)**

**CAUTION:** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

- The battery must be recycled or disposed of properly.
- Use the battery only in the specified equipment.

## Caring for Your Device

Taking good care of your device will ensure trouble-free operation and reduce the risk of damage to your device:

- Keep your device away from excessive moisture and extreme temperatures.
- Do not place anything on top of your device or drop objects on your device.
- Do not drop your device or subject it to severe shock.
- Do not subject your device to sudden and severe temperature changes. This could cause moisture condensation inside the unit, which could damage your device. In the event of moisture condensation, allow your device to dry out completely before use.
- The screen surface can easily be scratched. Avoid touching it with sharp objects. Non-adhesive generic screen protectors designed specifically for use on

portable devices with LCD panels may be used to help protect the screen from minor scratches.

- Never clean your device when it is turned on. Use a soft, lint-free cloth to wipe the screen and the exterior of your device.
- Do not use paper towels to clean the screen.
- Never attempt to disassemble, repair or make any modifications to your device. Disassembly, modification or any attempt at repair could cause damage to your device and even bodily injury or property damage and will void any warranty.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as your device, its parts or accessories.
- Do not expose your device to extreme heat or direct sunlight for prolonged periods. Overheating may damage your device.
- Do not use alcohol or any abrasive material when cleaning the accessories.
- Do not expose the accessories to extreme heat or direct sunlight for prolonged periods.
- Store the accessories in a cool and dry place.

## **Federal Communication Commission Interference Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



## **FCC Caution:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.

FOR PORTABLE DEVICE USAGE (<20cm from body/SAR needed)

NOTE: The country code selection is for non-US models only and is not available to all U.S models. Per FCC regulation, all Wi-Fi products marketed in U.S must be fixed to US operation channels only.

## **RF Exposure Information (SAR)**

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S.

Government. The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 4.0W/kg (Head 1g SAR 1.6W/kg). Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR

is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. The highest reported SAR value for Limb SAR (10g) is 1.15 W/kg and the highest reported Front-of-Face SAR (1g) is 1.19 W/kg. While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirements.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines.

SAR information on this model device is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid).

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of 10mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

### **§15.19 (a)(3)**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **§15.21**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **WEEE**

This device must not be disposed of as normal household waste, in accordance with the EU directive for waste electrical and electronic equipment (WEEE - 2002/96/EC). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.

# Warranty Information

## Warranty Period

The manufacturer warrants this device is free from defects in material and workmanship under normal use and service for twelve (12) months commencing upon the date of purchase by the first consumer purchaser. If proof of purchase cannot be provided, the manufacture date as recorded by manufacturer based upon the serial number will be deemed to be the start of Warranty Period.

## Limited Warranty Statement

The consumer should never attempt to open or disassemble the device and doing so may cause damage that voids your warranty.

The device is equipped with an internal rechargeable battery that is non-removable.

This warranty does not cover defects resulting from:

- (1) Improper or unreasonable use or maintenance
- (2) Failure to follow operating instructions; accident; excess moisture; insects; lightning; power surges; connections to improper voltage supply;
- (3) Unauthorized alteration or modification of original condition;
- (4) Damages caused by inadequate packing or shipping procedures;
- (5) Devices purchased from unauthorized dealers.

During the warranty period, manufacturer will, at its sole option, (using new or refurbished replacement parts), repair any defective devices. Repaired devices will be warranted for a period equal to the remainder of the original Limited Warranty on the original device or for NINETY (90) days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of the manufacturer.

The warranty is good only to the original purchaser of the device during the warranty period as long as it is in the US.

### **Disclaimer of Warranties; Exclusion of Liability**

Except as set forth in the express warranty contained on the warranty page enclosed with the device, the purchaser takes the device "AS IS," and manufacturer makes no express or implied warranty or any kind whatsoever with respect to the product, including but not limited to the merchantability of the product or its fitness for any particular purpose or use; the design, condition or quality of the device; the performance of the product; the workmanship of the product or the components contained therein; or compliance of the product with the requirements of any law, rule, specification or contract pertaining thereto. Nothing contained in the instruction manual shall be construed to create an express or implied warranty of any kind whatsoever with respect to the device. In addition, manufacturer shall not be liable for any damages of any kind resulting from the purchase or use of the device or arising from the breach of the express warranty, including incidental, special or consequential damages, or loss of anticipated profits or benefits. Manufacturer is not liable for performance issues or incompatibilities caused

by your editing of registry settings, or your modification of operating system software. Using custom operating system software may cause your device and applications to work improperly. Your carrier may not permit users to download certain software, such as custom OS. If your carrier prohibits this, if you attempt to download software onto the device without authorization, you will be notified on the screen that the device will no longer operate and be instructed to power down the device. You must then contact your carrier to restore the device to the carrier-authorized settings.

**Contact Verizon Customer Service at  
1-800-922-0204.**

## **IEEE 1725 Battery Safety Statement**

- Do not disassemble or open, crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard. Only authorized service providers shall replace battery.
- Promptly dispose of used batteries in accordance with local regulations.
- Avoid dropping the Wearable Product. If the Wearable Product is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard. For Wearable that utilizes a USB port as a charging source, the Wearable's user manual shall include a statement that the phone shall only be connected to CTIA-certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

- The recommended minimum age of a child who uses this Wearable is 3 years old.
- For Wearable with power supplies not intended to be handled by children: “As with all electrical products, precautions should be observed during handling and use to prevent electric shock. The power supply (adapter) should not be handled by the children.”
- For Wearable with power supplies (adapter) intended to be handled by children: “As with all electrical products, precautions should be observed during handling and use to prevent electric shock. The child should be very careful while handling the power supply (adapter), in particular plugging the power supply into the receptacle (power outlet).”
- The Wearable product, including power supply should not be left in the rain or subjected to exposure to water. If cleaning is necessary do not immerse in water; wipe clean with damp cloth.
- The Wearable product, including power supply should not be dropped, crushed (stepped on) or otherwise abused.
- The children should be careful with the interconnect cable (wiring) between the power supply (adapter) and the Wearable product, in particular as a potential trip hazard.
- An adult should inspect the Wearable product, including power supply, periodically for damage, and replace if necessary. Similarly, if a child notices damaged/broken parts, this should be reported to the guardian/caregiver immediately so that the damaged parts can be replaced.





