



 **KYOCERA** | **K323**

user guide

User Guide for the Kyocera K323 Phone

This manual is based on the production version of the Kyocera K323 phone. Software changes may have occurred after this printing. Kyocera reserves the right to make changes in technical and product specifications without prior notice. The products and equipment described in this documentation are manufactured under license from QUALCOMM Incorporated under one or more of the following U.S. patents:

4,901,307 5,109,390 5,267,262 5,416,797 5,506,865
5,544,196 5,657,420 5,101,501 5,267,261 5,414,796
5,504,773 5,535,239 5,600,754 5,778,338 5,228,054
5,337,338 5,710,784 5,056,109 5,568,483 5,659,569
5,490,165 5,511,073

The Kyocera Wireless Corp. ("KWC") products described in this manual may include copyrighted KWC and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for KWC and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the KWC products may not be modified, reverse engineered, distributed or reproduced in any manner not permitted by law. Furthermore, the purchase of the KWC products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of KWC or any third party software provider, except for the normal, non-exclusive royalty-free license to use that arises by operation of law in the sale of a product.

Kyocera is a registered trademark of Kyocera Corporation. Doodler, Brick Attack and Race 21 are trademarks of Kyocera Wireless Corp. QUALCOMM is a registered trademark of QUALCOMM Incorporated.

Openwave is a trademark of Openwave Systems Incorporated. eZiText is a registered trademark of Zi Corporation. TransFlash is a trademark of SanDisk Corporation.

Get It Now is a service mark of Verizon Wireless. All other trademarks are the property of their respective owners.

Copyright © 2006 Kyocera Wireless Corp. All rights reserved.

Ringer Tones Copyright © 2000-2002 Kyocera Wireless Corp.

82-N8865-1EN, Rev. 001

Bluetooth Certification

The Kyocera K323 phone is certified with Bluetooth SIG, Inc. ID number B03279.

FCC/IC Notice

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Kyocera Wireless Corp. (KWC) supplied and approved standard case CV90-M2293-01, premium case CV90-M2294-01, or holster CV90-M2288-01.

Other accessories used with this device for body-worn operations must not contain any metallic components and must provide at least 15 mm separation distance including the antenna and the user's body.

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio

frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population.

The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.*

Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value.

This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

Body-worn measurements differ among phone models, depending upon availability of accessories and FCC requirements. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines.

SAR information on this model phone is on file with the FCC and can be found under the Display Grant section <http://www.fcc.gov/oet/fccid> after searching on the FCC ID: OVFKWC-K24B. Additional information on SAR can be found on the Cellular Telecommunications and Internet Association (CTIA) web-site at <http://www.wow-com.com>.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Caution

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and user's authority to operate the equipment.

Optimize your phone's performance

Use the guidelines on page 2 to learn how to optimize the performance and life of your phone and battery.

Air bags

If your vehicle has an air bag, **DO NOT** place installed or portable phone equipment or other objects over the air bag or in the air bag deployment area. If equipment is not properly installed, you and your passengers risk serious injury.

Medical devices

Pacemakers—Warning to pacemaker wearers: Wireless phones, when in the 'on' position, have been shown to interfere with pacemakers. The phone should be kept at least six (6) inches away from the pacemaker to reduce risk.

The Health Industry Manufacturers Association and the wireless technology research community recommend that you follow these guidelines to minimize the potential for interference.

- Always keep the phone at least six inches (15 centimeters) away from your pacemaker when the phone is turned on.
- Do not carry your phone near your heart.
- Use the ear opposite the pacemaker.
- If you have any reason to suspect that interference is taking place, turn off your phone immediately.

Hearing aids—Some digital wireless phones may interfere with hearing aids. In the event of such interference, you may want to consult Verizon Wireless or call the customer service line to discuss alternatives.

Other medical devices—If you use any other personal medical device, consult the manufacturer of the device to determine if it is adequately shielded from external RF energy. Your physician may be able to help you obtain this information.

In health care facilities—Turn your phone off in health care facilities when instructed. Hospitals and health care facilities may be using equipment that is sensitive to external RF energy.

Potentially unsafe areas

Posted facilities—Turn your phone off in any facility when posted notices require you to do so.

Aircraft—FCC regulations prohibit using your phone on a plane that is in the air. Turn your phone off or switch it to Airplane Mode before boarding aircraft.

Vehicles—RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer of the device to determine if it is adequately shielded from external RF energy.

Blasting areas—Turn off your phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres—Turn off your phone when you are in any area with a potentially explosive atmosphere. Obey all signs and instructions. Sparks in such areas could cause an explosion or fire, resulting in bodily injury or death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include:

- fueling areas such as gas stations
- below deck on boats
- transfer or storage facilities for fuel or chemicals
- vehicles using liquefied petroleum gas, such as propane or butane
- areas where the air contains chemicals or particles such as grain, dust, or metal powders
- any other area where you would normally be advised to turn off your vehicle engine

Use with care

Use only in normal position (to ear). Avoid dropping, hitting, bending, or sitting on the phone.

Keep phone dry

If the phone gets wet, turn the power off immediately and contact your dealer. Water damage may not be covered under warranty.

Resetting the phone

If the screen seems frozen and the keypad does not respond to keypresses, reset the phone by completing the following steps:

1. Remove the battery door.
2. Remove and replace the battery.

If the problem persists, return the phone to the dealer for service.

Accessories

Use only Kyocera-approved accessories with Kyocera phones. Use of any unauthorized accessories may be dangerous and will invalidate the phone warranty if said accessories cause damage or a defect to the phone.

To shop for K323 phone accessories, visit www.kyocera-wireless.com/store. You may also call us at 800-349-4188 (U.S.A. only) or 858-882-1410.

Radio Frequency (RF) energy

Your telephone is a radio transmitter and receiver. When it is on, it receives and sends out RF energy. The Verizon Wireless network controls the power of the RF signal. This power level can range from 0.006 to 0.6 watts.

In August 1996, the U.S. Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. These guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies in the following reports:

- ANSI C95.1 (American National Standards Institute, 1992)
- NCRP Report 86 (National Council on Radiation Protection and Measurements, 1986)
- ICNIRP (International Commission on Non-Ionizing Radiation Protection, 1996)

Your phone complies with the standards set by these reports and the FCC guidelines.

E911 mandates

Where service is available, this handset complies with the Phase I and Phase II E911 Mandates issued by the FCC.

Hearing Aid Compatibility (HAC) with Mobile Phones

Some mobile phones and hearing devices (hearing aids and cochlear implants), when used together, result in buzzing, humming, or whining noises detected by the user. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees and results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings— Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings— Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you choose the proper rating for your mobile phone. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

For more information about hearing aid compatibility, visit the FCC's Consumer & Governmental Affairs Bureau Web site at www.fcc.gov/cgb/dro.

Hearing Aid Compatibility (HAC) rating: M4

Battery and charger specifications

Charger	Input	Output
CV90-G2588-01	100-240VAC 50/60Hz 0.2A	4.2VDC 0.6A
CV90-G2589-01	100-240VAC 50/60Hz 0.3A	4.5VDC 1.2A
Standard Battery:		
CV90-P3030-05 3.7V 1000mAh		
Standard Robust Battery:		
CV90P3031-03 3.7V 900mAh		
Extended Battery:		
CV90-P3032-03 1800mAh		

Kyocera Wireless Corp.

10300 Campus Point Drive, San Diego, CA 92121
U.S.A.

Visit us at www.kyocera-wireless.com

CONTENTS

1	Getting Started	1	Creating a secure environment	39	
	Installing the battery	1	Understanding roaming	39	
	Getting to know your phone	3	Setting position location	41	
	How to access menu items	5			
2	Making and Answering Calls	8	8	Using the Camera	43
	Making a call	8		Taking a picture	44
	Silencing an incoming call	9	9	Using Voice Recognition	46
	Using the speakerphone	9		Setting up voice dialing	46
	Speed dialing	10		Making a call using voice tags	46
	Setting up voicemail	11		Making a call using digit dialing	47
3	Entering Letters, Numbers, and Symbols	14		Training voice recognition	49
4	Storing Contacts	17	10	Using Tools	50
	Creating a new contact	17		Calculator	50
	Adding a code or extension	18		Calendar	50
	Customizing your contacts	18		Alarm Clock	52
	Creating and using groups	19		World Clock	52
	Editing a contact	20		Notepad	53
	Erasing a contact	20		To Do List	54
	Customizing a phone number	20	11	Get It Now	55
	Finding contact information	20		Downloading an application	55
5	Messaging	22		Removing an application	56
	Sending text messages	22	12	Using Bluetooth® Wireless Technology	57
	Customizing message settings	23	13	Connecting to the Internet	61
	Retrieving text messages	26		Using the Web Browser	61
6	Multimedia Messaging	29	14	Getting Help	62
	Sending multimedia messages	29	15	Warranty	63
	Viewing multimedia messages	30		Index	65
7	Customizing Your Phone	32			
	My Account	33			
	Silencing all sounds	33			
	Choosing ringers	33			
	Setting sounds for your phone	33			
	Personalizing the screen	36			

1 GETTING STARTED

Installing the battery

Your Kyocera K323 phone comes with a removable lithium ion (LiIon) battery. **Fully charge the battery before using the phone.**

Note: You must use a Kyocera-authenticated battery in your phone. If you attempt to use a battery that has not been authenticated you will receive a security warning. Visit www.verizonwireless.com to obtain a Kyocera-authenticated battery.

To install the battery:

1. Hold the phone face down.
2. Slide the battery door downward to remove it.
3. Place the battery in the phone casing with the metal contacts facing towards the bottom end of the phone.
4. Replace the battery door by sliding the notches into the openings at the bottom and outside edges of the battery casing.
5. Slide the door up to secure the cover into place.




Charging the battery



You must have at least a partial charge in the battery to make or receive calls.

To charge the battery:

1. Connect the AC adapter to the jack on the bottom of the phone.
2. Plug the adapter into a wall outlet.



The battery icon in the upper-right corner of the screen tells you whether the phone is:

- Charging (the icon is animated)
- Partially charged 
- Fully charged 

Note: The battery will not charge if you use the phone while it is connected to an AC adapter.

Recharging the battery

You can safely recharge the battery at any time, even if it has a partial charge.

Note: To remove the battery, make sure the phone is powered off.

Caring for the battery

General safety guidelines


- Do not take apart, puncture, or short-circuit the battery.
- If you have not used the battery for more than a month, recharge it before using your phone.
- Avoid exposing the battery to extreme temperatures, direct sunlight, or high humidity.
- Never dispose of any battery in or near a fire. It could explode.


Common causes of battery drain

- Playing games or using the Web.
- Taking pictures with the flash on.
- Keeping backlighting on.
- Operating in digital mode when far away from a base station or cell site.
- Using data cables or accessories.
- Operating when no service is available, or service is available intermittently.
- High earpiece and ringer volume settings.
- Repeating sound, vibration, or lighted alerts.


Getting to know your phone

The phone is shown here in open position. You must open the flip to use the keys on the lower portion of the phone. When the phone is closed, the keys are locked to prevent accidental key presses.

- ① **Home screen.**
- ② **Speakerphone key** activates the speakerphone and answers incoming calls.
- ③ **Left softkey** accesses Message menu and submenus.
- ④ **Navigation key** scrolls through lists and text entry fields and accesses shortcuts from the home screen.
- ⑤ **Send/Talk key** starts or answers a call. Press once to display the Recent Calls list.
- ⑥ **CLR key** erases characters in text entry and returns you to the previous screen.
- ⑦ **Keypad** for entering numbers, letters, or symbols.
- ⑧ *** / Shift key** changes the text mode in text entry.
- ⑨ **Right softkey** accesses the Contacts directory and other menu options.
- ⑩ **OK key** accesses the main menu. Selects a menu item or option.
- ⑪ **End/Power key** turns the phone on and off, ends a call or browser session, and returns you to the home screen.
- ⑫ **# / Space key** enters a space during text entry. Press and hold to activate or deactivate Silent mode.
- ⑬ **0 / Next key** cycles through word choices during text entry. Press and hold to activate or deactivate Voice dialing.
- ⑭  **Jack for AC adapter** (included) and data cable (sold separately).



- ⑮ ⚠ **Jack for Hands-free Headset** only (sold separately).
- ⑯ **Volume key** to raise or lower ringtone volume.
- ⑰ **Camera key** activates Camera mode. To activate Camera mode, press and hold until you hear two beeps.
- ⑱ **External earpiece.**
- ⑲ **Camera lens.**
- ⑳ **External screen** displays time, caller ID, signal and battery strength.
- ㉑ **Camera Flash/Message Indicator Light** light flashes when taking a picture or lights when you have a message or missed call.










⚠ **Warning:** Inserting an accessory into the incorrect jack will damage the phone.

Using menus




The contents of the main menu are as follows:






Contacts	Recent Calls	Settings & Tools	GET IT NOW	Messaging
New Contact	Missed	My Account	Get Tunes & Tones	New Msg
Contact List	Received	Tools	Get PIX	Inbox
Groups	Dialed	Sounds Settings	Get Fun & Games	Sent
Speed Dials	All	Display Settings	Get News & Info	Drafts
	View Timers	Phone Settings	Get Going	Voicemail
		Call Settings	Get Extras	Email
		Bluetooth®		Mobile IM
		Memory		Chat
		Phone Info		

How to access menu items

- Press  to view the home screen.
- Press  to select **Contacts**.
- Press  to select **Message**.
- From the home screen, press  to select **Menu**, then press  left or right to view main menus. Press  down or up to select submenu options
- or -
press a number on the keypad that corresponds to a submenu.
- Press  to back up a menu level.

How to Access menu items example:























1. Press  to view the home screen
2. Press  to select **Menu**.
3. Press  left or right to select **Settings & Tools**.

4. Press  up or down to select **Display Settings** and then press 
- or -
Press 4 on the phone's keypad to select **Display Settings**.
5. Press  up or down to select **Display Themes** and then press 
- or -
Press 6 on the phones keypad to select **Display Themes**.
6. Select an option and press .

Note: An instruction in this manual may read:
Menu → Settings & Tools → Tools.
The “→” in this manual's instruction tells you what menu option to select next.

Performing basic functions

Note: The phone must be powered ON to perform the following functions.

To...	From the home screen...
Turn the phone on	Press  .
Turn the phone off	Press and hold  .
Make a call	Enter the number and press  or press and hold  to initiate voice dialing. Contact must have voice tag assigned (see page 46).
End a call	Press  .
Answer a call	Press  .
Adjust volume during a call	Press  up or down.
Acknowledge a message alert	Press  to select View now or press  down to select View later and then press  .
Quiet the ringer on an incoming call	Press  to select Quiet and then press  to answer or press  to select Ignore . The incoming call will go to your voicemail.
Access voicemail	Press and hold  and follow the system prompts.
Access messaging	Press  .
Access Contacts list	Press  .
Scroll menus	Press  up, down, left or right.
Select menus	Highlight a menu or option and press  .
Access Recent Calls List	Press  once.
Activate Camera mode	Press and hold the side camera key  . Focus on the image and press  to select TAKE to take a picture.
Access Shortcuts	Press and hold  up, down, left or right.
Verify your phone number	Select Menu → Settings & Tools → Phone Info → My Number

Understanding screen icons

These icons may appear on your phone's screen.



The phone is operating in IS2000 (1X) digital mode.



The phone is operating in analog mode.



The phone is operating in IS95 digital mode.



The phone is not receiving a signal. You cannot make or receive calls.



Standalone Mode



The phone is receiving a signal. You can make and receive calls. Fewer bars indicate a weaker signal.



The phone is roaming outside of its home service area.



Voice Privacy



SSL



A call is in progress.



The phone is receiving a data call.



The phone is dormant.



TTY is enabled.



Location On, position location is set to Verizon Wireless and to emergency services.



Position location is set to emergency services only.



The phone is in privacy mode or is accessing a secure Web site.



Bluetooth® On



The battery is fully charged. The more black bars, the greater the charge.



The phone is set to sound the alarm only.



The phone is set to vibrate or to vibrate and then ring.



All sounds are off.



You have a missed call.



You have a voicemail message.



You have a new message.



You have a Calendar appointment



The alarm clock is set.



The phone is at the home screen. To access **Message**, press .



The phone is at the home screen. To access **MENU**, press .




The phone is at the home screen. To access **Contacts**, press .





Speakerphone

2 MAKING AND ANSWERING CALLS

Making a call

Make sure you are in an area where a signal can be received. Look for the  symbol on the home screen. The more bars you see in this symbol, the stronger the signal. If there are no bars, move to where the signal strength is better.



When the phone has been idle for a time, it changes to power save mode. Press any key to return to normal operating mode.

1. Open the flip.
2. Enter the phone number and press .
3. Press  or close the flip to end the call.

Voice or Digit dialing



You can make a voice call by speaking the name of the person/place you want to call
- or -
you can speak the digits of a phone number.

Note: Voice call requires that a contact be saved with a voice tag. See “Creating a voice tag for a contact” on page 46.

1. Press and hold .
2. Follow the voice prompts to initiate voice or digit dialing. The phone places the call.
3. Press  to end the call.





Answering a call

When a call comes in, the phone rings, vibrates, or lights up. The phone number of the caller appears on the screen if it is not restricted. If the number is stored in your Contacts directory, the contact name appears.


1. Open the flip.
2. Press  to answer the incoming call.
- or -
Press  to answer the incoming call and turn on the speakerphone.

Answering calls using the flip

You can set the phone to answer immediately when you open the flip. This feature does not apply to incoming data or fax calls.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Call Settings**→ **Answer Options**.
4. Press  to select **Flip Open**.




Other answer options are:

- **Any Key** sets the phone to answer a call by pressing any key.
- **Send Only** sets the phone to answer voice calls by pressing the  key only.



- **Auto Answer** sets the phone to automatically answer a voice call after 5 seconds when the flip is open.

Auto Retry




Allows the phone to automatically reattempt a call when the phone receives a network busy signal.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Call Settings** → **Auto Retry** → **On**.

Adjusting the volume during a call



- To adjust the earpiece or speakerphone volume during a call, press   up or down.

Silencing an incoming call

- Press  to **Quiet** a call.
Press  if you choose to answer the call.
- or -
- Press  to select **Ignore**. The call goes to voicemail.



Note: This action silences the current call only. The next call will ring as normal. In the absence of voicemail, this feature drops the call.

Redialing a number

- To redial a recent call, from the home screen press  to open Recent Calls list. Highlight a phone number or name and press .





Calling a saved number

If you have already saved a phone number, you can use the Contacts list to find it quickly.



1. From the home screen, press  to select **Contacts**.
2. Highlight the name of the contact you want to call and press  to dial the number.

Using the speakerphone

Your Kyocera K323 phone has a built-in speakerphone.

- To turn on the speaker, open the flip and press . If you press  during an incoming call alert, you answer the call.
The  icon at the bottom of the phone screen indicates that the speakerphone is on.
- To turn off the speakerphone, press .




Dialing a three-way conference call*

To dial a three-way conference call, dial the first number and press , dial the second number, press  again.

*May not be available in your area, check with Verizon Wireless.

Dealing with missed calls

When you have missed a call, “Missed Call” appears on your screen unless the caller leaves a voicemail.

- To view the call, press  to select **View now**.
- To view later, press  down to select **View later** and then press .








Viewing recent call details

Details on the last 60 calls you made, received, or missed are stored in the Recent Calls list and are identified by the following icons:








 Dialed calls  Received calls

 Missed calls








Viewing recent calls

1. Press  to select **Menu**.
2. Press  left or right to select **Recent Calls**.
3. Press  up or down to select **Missed**, **Received**, **Dialed**, or **All** and press .
4. Select a recent call and press  to select **Open**. Details of the call are displayed.
5. Press  to return to the selected list
- or -
Press  to select **Options** and follow the prompts.

Calling recent calls

1. Press  to view **ALL CALLS**.
2. Highlight the number you want to call and press .
- or -
1. Press  to select **Menu**.
2. Press  left or right to select **Recent Calls**.
3. Press  up or down to select **Missed**, **Received**, **Dialed**, or **All** and press .
4. Highlight the number you want to call and press .

Erasing recent calls

1. Press  to select **Menu**.
2. Press  left or right to select **Recent Calls**.
3. Press  up or down to select **Missed**, **Received**, **Dialed**, or **All** and press .
4. Highlight the number you want to erase and press  to select **Options**.
5. Press  up or down to select **Erase** and then press .


Speed dialing

Before you can use speed dialing, you must save a phone number as a contact and assign a speed dial location to it.

- To add a speed dial location to a saved or new contact, see “Customizing a phone number” on page 20.

Using speed dialing

To call a contact that has a speed dial location:




- From the home screen, enter the one, two, or three digit speed dialing location and press .

One Touch dialing

One Touch dialing is the fastest way to speed dial a contact that has a speed dial location.

Note: You must (1) enable One Touch dialing on your phone and (2) have a speed dial location assigned to a contact.



Enabling OneTouch dialing

- Press  to select **Menu**.
- Press  left or right to select **Settings & Tools**.
- Press  up or down to select **Call Settings** → **One Touch Dial** → **On**.

Using One Touch dialing


To call a contact that has a speed dial location:

- From the home screen, press and hold the speed dialing number. If it is a two or three digit number, press the first digits briefly, then press and hold the last digit.



For example, if the speed dialing location is 15, press  briefly, then press and hold .

Setting up voicemail

Before your phone can receive voicemail messages, you must set up a password and record a personal greeting with Verizon Wireless. When you have set up your voicemail, all unanswered calls to your phone are automatically transferred to voicemail, even if your phone is in use or turned off.

- From the home screen, press and hold .
- Follow the voice tutorial to create a password and record a greeting.

Accessing voicemail


- From the home screen, press and hold .
- Press  and then enter your password.
- Follow the voice prompts to access your messages.






Note: If you are having trouble accessing your voicemail, contact Verizon Wireless.

Changing the default number for calling voicemail


You can choose to change the default phone number for calling voicemail.

To change the default number:


- Press  to select **Message**.

2. Press  to select **Settings**.
3. Press  up or down to select **All Msg**.
4. Press  up or down to select **Voicemail #** and press .
5. Enter the new voicemail number and press .

Checking voicemail messages


When a voice message is received, your screen displays “NEW VOICEMAIL” along with the  symbol at the top of your screen.

If you see “NEW VOICEMAIL”






- Press  to select **Listen now**, which initiates a call to your voicemail number.

Follow the prompts to retrieve the message.

To clear the screen without checking messages:

- Press  up or down to select **Listen later**.





If you see only the symbol

1. Press and hold  to initiate a call to your voicemail number.
 2. Follow the prompts to retrieve the message.
- or -
Press  to select **Message**.
Press  up or down to select **Voicemail** and press .
- Press  again to select **Call** to initiate a call to your voicemail number.

Note: You can set the phone to beep or vibrate every five minutes to remind you that you have voicemail. See “Setting message alerts” on page 35.

Checking new Voicemail received


You can check to see if you have received new voicemail. When no new messages are in the Voicemail, the screen will display “No new messages.”

1. Press  to select **Message**.
2. Press  up or down to select **Voicemail**.
 - Press  to select **CALL** to dial voicemail.
 - Press  to select **Clear**.

Note: If no messages are in your Voicemail box, **Clear** will not be present.

Calling emergency services



Note: Regardless of your 3-digit emergency code (911, 111, 999, 000, etc.), your phone operates as described below.

- Dial your 3-digit emergency code and press .

You can call the code even if your phone is locked or your account is restricted. When you call, your phone enters **Emergency mode**. This enables the emergency service exclusive access to your phone to call you back, if necessary. To make or receive regular calls after dialing the code, you must exit this mode.

To exit Emergency mode






When you have completed the emergency call:

1. Press  to select **Exit**.
2. Press  again to confirm your choice.

Note: To determine who has access to your location, see “Setting position location” on page 41.

Tracking calls

You can view the number and duration of calls made and received on your phone.

1. Press  to select **Menu**.
2. Press  left or right to select **Recent Calls**.
3. Press  up or down to select **View Timers** and press .
4. Press  to scroll and view timers.

To reset a timer to 0, select a timer and press



 to select **Reset** and press .


- or -

press  to select **Reset All** to reset all timers and press .

Timing your calls

You can set your phone to beep 10 seconds before each minute passes when you are on a call.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.

3. Press  up or down to select **Sounds Settings** → **Service Alerts** → **Minute Beep** → **On**.

Other alert options are:


- **ERI Enhanced Roaming Indicator**, sets an alert notification when the phone is roaming.
- **Call Connect** sets an alert notification when there is data call connection failure.

3 ENTERING LETTERS, NUMBERS, AND SYMBOLS

You can enter letters, numbers, and symbols in contacts, messages, and your banner.

Understanding text entry screens

The current text entry mode (and capitalization setting, when applicable) are indicated by icons.



Text entry modes

There are eight text entry modes:

Ezi	Rapid entry, case change
EZI	Rapid entry, upper case letters
ezi	Rapid entry, lower case letters
Abc	Case change
ABC	Upper case letters
abc	Lower case letters
123	Numbers only
Symbols	Add symbol


Note: The mode you start in depends on the task you are doing. For example, when entering a phone number, you're in number mode. When entering a name for a contact, you're in normal text mode. See "Changing modes" on page 15.

123 Entering numbers

- To enter a number while in **123** mode, press a number key once.
- To enter a number while in **abc** or **ezi** mode, press and hold a number key until the number appears on the screen.




abc Entering words letter by letter



1. Press a key once for the first letter, twice for the second letter, and so on. If your phone is set to Spanish, accented letters are available.
2. Wait for the cursor to move right and enter the next letter.

Note: To enter a space, press .


eZi Entering words quickly

When you press a series of keys using **ezi** mode, **ezi** checks its dictionary of common words and guesses at the word you are trying to spell.

1. For each letter of the word you want, press the key once. For example, to enter the word "any" press  →  → .




2. If the word doesn't match what you want, press  to look at other word matches.
3. When you see the word you want, press .

&?! Entering symbols

While entering text, you can enter symbols by pressing  until you see the symbol you want. Using this method, you have access to the following symbols:

. @ ? ! - , & : ' 1






To access the full set of symbols:




1. From the text entry screen, press  to select **Abc**.
2. Press  up or down to highlight **Symbols** and then press .
3. Press the number key corresponding to the symbol you want.

Switching default text entry modes

You can change the default text entry mode when creating a text message.

Note: This setting applies only to the text message body screen, not the "To" screen.



1. Press  to select **Message**
- or -
press  to select **Menu**
press  left or right to select **Messaging**.
2. Press  to select **Settings**.
3. Press  to select **All Msg**.

4. Press  up or down to select **Entry Mode** and press .
5. Choose the entry mode you want to change to and then press .


Changing modes

Sometimes you need to change modes. For example, to enter numbers in an email address while in **abc** mode, you must change to **123** mode, enter the numbers, and then change back to **abc** mode to complete the address.

To change text entry modes:













- Press and hold  until the icon for the mode you want appears at the top right of the text screen.
- or -
- Press  to select **Abc** and then select a different mode.

Capitalization settings

You can change capitalization at any time while entering text. Simply press  to choose upper or lower case while in **abc** mode.

Quick reference to text entry

This table gives general instructions for entering letters, numbers, and symbols.

To...	Do this...
Enter a letter	Use abc mode and press a key until you see the letter you want. For more information, see page 14.
Enter a number	Use 123 mode and press a key once to enter its number. For more options, see page 14.
Enter a symbol	Press  until you find the symbol you want. See page 15.
Enter a space	Press  .
Erase a character	Press  .
Erase all characters	Press and hold  .
Move the cursor right or left	Press  right or left.
Move the cursor up or down	Press  up or down.
Change text entry modes	Press and hold  .
Capitalize any letter	In abc mode, press and hold  . Choose ABC .
Lowercase any letter	In abc mode, press and hold  . Choose abc .
Initial Caps	In abc mode, press and hold  . Choose Abc .
Select soft options on the screen	Press the appropriate key,  or  .

4 STORING CONTACTS

Use your phone's Contacts directory to store information about a person or company. Each contact entry can have up to four phone numbers, one Fax number, and two email addresses.

The associated icon appears next to the number in your Contacts directory.



general



mobile



work



Email address








home





fax





Creating a new contact

1. From the home screen, enter the phone number you want to save, including the area code and press  to select **Save**.
2. Press  to select **Create New**.
3. Press  up or down to select a phone option: Mobile, Home, Work, Fax number, or email address and then press .
4. Enter a name for the contact.
 - If you need to learn how to enter letters, see “Understanding text entry screens” on page 14.
 - To add a symbol to the contact name, or to change the text entry mode, press  to select **Abc**.





5. Either save now or add more contact information.

- To save now, press  to select **Save**.
- To enter additional phone numbers, fax number, or email address press  down repeatedly. For help switching between numbers and letters for email or Web addresses, see “Changing modes” on page 15.

- or -

1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Press  to select **New Contact**.
3. Enter a name for the contact.
4. Press  down to select a field; Mobile, Home, Work, Fax number, or email address and then enter the number.
5. Press  to select **Save**.

Updating existing contact information

1. From the home screen, enter the new phone number for the existing saved contact, including the area code and then press  to select **Save**.
2. Press  up or down to select **Update Existing** and press .
3. Highlight the contact name and press .

- Press up or down to select a phone option: Mobile, Home, Work, Fax number, or email address.
- Press to save.

Adding a code or extension

When you save the phone number of an automated service, you may include a pause to stop dialing, for example, where you would wait to dial an extension.

- From the home screen, enter the phone number.
- Press to select **Options**.
- Select a type of pause:
 - 2-sec Pause** causes the phone to stop dialing for two seconds.
 - Wait** causes the phone to stop dialing until you press to select **Release**.
- Enter the remaining numbers.
- Press to select **Save**.

Customizing your contacts

You can customize each contact in your Contacts directory by assigning ringtones, pictures, and number types, or by classifying your contacts as Personal or Business.




Assigning ringtones

- Press to select **Menu**. This will take you to the Contacts menu.

- Select **Contact List** and press .
- Highlight the contact name and press to select **View**.
- Highlight and press to select **Edit**.
- Press to select **Set**.
- Press up or down to select from the list of ringtones
 - or -
 - press to select **Get New Ringtones** to purchase and download a new ringtone.
- Note:** Press to select **Play** to hear the sound of a ringtone.
- Press to select a ringtone.
- Press to select **Save**.

Assigning pictures










- Press to select **Menu**. This will take you to the Contacts menu.
- Select **Contact List** and press .
- Highlight the contact name and press to select **View**.
- Highlight and press to select **Edit**.
- Press to select **Set**.
- Press up or down to highlight a picture and press to assign it to your contact
 - or -
 - Press to select **Options**:
 - Take Pix** - press to select **Take Pix**. When you have taken the picture, press to select **Select**. Press to select **Save**.


- **PIX Place** - Follow the prompts to purchase and download a new picture.
 - **Get New** - Select **Get New** and press  . Press  to select **Get New App.** and follow the prompts to purchase and download a new picture.
7. Press  to select **Save**.


Creating and using groups

You can create and save a list of multiple recipients. Your K323 phone stores five group lists with up to 10 recipients per list.

Creating Groups





1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Select **Groups** and press  .
3. Press  to select **New**.
4. Enter a name for the group. For help entering text, see page 14.
5. Press  to select **Save**.
6. Press  up or down to highlight the new group and then press  .
7. Press  to select **Add**.
8. Highlight a contact you want to add to the group and press  to select **MARK**. A checkmark appears in the box. Press  up or down to select and repeat for each contact you wish to add.

Note: You can choose to press  to select **Mark All** to add all contacts to the group.



9. Press  to select **Done** when you have finished adding contacts.








Group options

Options may vary with the group you select.





1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Select **Groups** and press  .
3. Highlight a group name and press  to select **Options**.
4. Highlight an option and press  :
 - **Send Txt Msg** brings you to the text messaging screen.
 - **Send Pix Msg** brings you to the picture messaging screen.
 - **Rename** to rename the group.
 - **Erase** erases the group.
 - **Add** to add and remove contacts.
5. Enter the new information and follow the prompts.
6. Select **Save**, if necessary.

Classifying contacts as Personal or Business






1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Select **Contact List** and press  .

3. Highlight a contact name and press  to select **View**.
4. Highlight  and press  to select **Edit**.
5. Press  to select **Set**.
6. Press  up or down to select **Business** or **Personal** and then press .
7. Press  to select **Save**.


Editing a contact







1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Select **Contact List** and press .
3. Highlight the contact name and press  to select **Edit**.
4. Enter your changes and press  to select **Save**.

Erasing a contact

1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Select **Contact List** and press .
3. Highlight the contact name and press  to select **View**.
4. Press  to select **Erase** and then press  to erase it.

Customizing a phone number



1. Press  to select **Menu**. This will take you to the Contacts menu.



2. Select **Contact List** and press .
3. Highlight the contact name and press  to select **View**.
4. Press  to select **Edit**.
5. Press  to select **Options**.
6. Highlight an option and press 
 - **Set Speed Dial** assigns or removes the speed dial location.
 - **Set Voice Dial** to record a voice tag so you can call a contact using voice recognition (VR). For more information, see page 46.
 - **Set as Default** sets the phone number as the default.
 - **Add Pause** allow you to add a pause to the phone number.
7. Enter the new information and follow the prompts.
8. Press  to select **Save**.

Finding contact information


To find a phone number or contact, you can (1) search the Contacts directory, or (2) use Fast Find.

Searching the Contacts directory

1. Press  to select **Contacts**.
 - or -
 - Press  to select **Menu**.




2. Press  up or down to select **Contact List, Groups, or Speed Dials** and then press .

Note: To quickly get down the Contact List, enter the first letter of the contact. The menu skips to that letter of the alphabet.



3. To call the contact, highlight the number and press .

Setting Fast Find

With Fast Find, you press one or two keys to view close matches of the number you are looking for.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Call Settings** → **Fast Find** → **On**.

Using Fast Find

1. From the home screen, press the keys corresponding to the letters of the name you want to find. A matching contact or speed dial entry appears.
2. Press  down to scroll through matching entries.
3. Highlight the name you want then press  to call the number.

5 MESSAGING


This chapter describes how to send, receive, and erase text and picture messages from your phone. For information on voicemail messages, see “Setting up voicemail” on page 11.


Important: The features and menus described in this chapter may vary depending on services available in your area. Check with Verizon Wireless for details and possible usage charges.


Sending text messages


You can only send text messages to phones that are capable of receiving them or to email addresses.


One of the following symbols appears next to each message:


-
-  The message has been sent.


 -  The message has been delivered.

 -  The message has an attachment.







 -  The message is pending.

 -  You have a new message.



 -  The message has been read.





 -  The message has not been read.

Creating a text message

1. Press  to select **Message**.
2. Press  up or down to select **New Msg** and press  twice.
- or -
Press  to select **Menu**.
Press  left or right to select **Messaging**.
Press  up or down to select **New Msg** → **TXT Msg**.
3. Enter a recipient's phone number or email address.

Add another recipient if desired:

Press  down to access the next recipient field and then press  when you have finished adding recipients.


Tip: To add recipients from **From Contacts**, **Recent Calls**, or **Groups folders** press  to select **Add**. Select an option and highlight a contact. Press  to select **Mark** or press  to select **Mark All**. When you have finished adding the recipients press  to select **Done**.

Note: You can send a message to up to 10 recipients at once. The messages will be sent one at a time, once to each addressee.

4. Enter the message. To learn how to enter text or symbols, see “Understanding text entry screens” on page 14.



- or -

Add QuickText to your message. See
“Including prewritten text” for information.

5. Press  to select **Send**. See “Setting sending options” on page 23 for information about how and when you want the message to be received.

Including prewritten text

During text entry, you can insert QuickText into your message.




1. From the text entry screen, select **Options**.
2. Select **Add QuickText**.
3. Scroll through the list of options and press  to select one.
4. When you have finished your message, press  to select **Send**. See “Setting sending options” on this page for information about how and when you want the message to be received.

Customizing message settings

To make messaging easier, you can customize settings for sending and receiving messages.

Setting sending options

When you are ready to send a message, you have several options for how and when you want the message to be received. **Set Priority Level, Validity Period, Deferred Deliv.** and the option to **Add a Contact** or **Save As Draft**

1. Once you have completed the message, press  to select **Options**:
 - **Add Contact** returns to the “Send To” screen to add another recipient without losing the message. Select a contact and press  to select **ADD**.
 - **Save As Draft** saves the message in your **Drafts** folder. This prevents the message from being deleted if you have activated AutoErase and enables you to send the message to others.
 - **Priority Level** labels the message as “Urgent.”
 - **Validity Period** defines expiration period limit for a message.
 - **Deferred Deliv.** allows you to set a future date and time when a message is to be delivered.
 - **Cancel Msg** allows you to cancel the message.
2. Press  to select **Send**.

Adding a signature

The signature you create does not display in the message creation screen; however, the signature is included at the end of all outgoing messages and is counted as characters in your messages.

To create a signature:

1. Press to select **Message**.
2. Press to select **Settings**.
3. Press up or down to select **All Msg**.
4. Press up or down to select **Signature**.
5. Enter your signature in the text field.
6. Press to save the setting.

Adding a callback number

Include a callback number with the message to let the recipient know at what number they can call you back.

1. Press to select **Message**.
2. Press to select **Settings**.
3. Press up or down to select **All Msg**.
4. Press up or down to select **Callback #**.
5. Press down to select **On**.

Note: Press down to enter a different callback number in the number field.

6. Press to save the setting.

Including Graphics or Sound

During text entry, you can insert Graphics or Sound into your message. However, if the graphic or sound exceeds the space limit a message will display “Exceeds available space”.

1. From the text entry screen, select **Options**.
2. Select **Add Graphic** or **Add Sound**.
3. Scroll through the list of options.

Note: Press to select **View** if you chose Graphic or press to select **Play** if you chose Sound.


4. Press to select it.

When you have finished your message, press to select **Send**.

If you cannot send messages

You may not be able to send or receive messages if your phone's memory is nearly full, or if service is not available at the time. To free up memory, erase old messages. See “Erasing messages” on page 27.

Understanding appended messages.





If you go over the character limit for a single message, the phone may automatically append an empty segment to your message to make space.



Important: Verizon Wireless will charge you for each message segment.

When you start a message, the maximum character limit appears once you are in the message entry field. This number counts down as you enter characters, until it reaches 0.

If you continue to enter text after this counter reaches 0, a message segment may be appended. When you reach the message size limit, you are prompted to edit the message or alerted that the message is being appended.

Receiving incoming calls while creating messages

- If you don't wish to answer the call, press  to select **Ignore**. The phone returns to the message screen.
- To answer the call, press . Your message is saved to the Drafts folder.



Note: To return to the message, from the home screen, press  to select **Message**. Press  up or down to select **Draft**.



Viewing sent messages

You can check the status of messages you have sent as long as they have been saved to the **Sent** folder.










Setting the Sent folder

The **Sent** default is set to disabled to conserve memory. If you want to save your sent messages:

1. Press  to select **Message**.
2. Press  to select **Settings**.



3. Press  to select **All Msg**.
4. Press  up or down to select **Auto Save**.
 - Select **On** to save all sent messages to the **Sent** folder.
 - Select **Prompt** to alert you to choose whether or not to save your message.


To view Sent messages

1. Press  to select **Message**.
2. Press  up or down to select **Sent** and press .
3. Press  up or down through the list of messages.
4. Select a message and press  to select  **Open**. You can choose to press  to **Erase** the message, press  to **RESEND** the message, or press  to choose other options.

Viewing failed or pending messages

Failed or pending messages are stored in your **Sent** folder. To view **Sent** folder:

1. Press  to select **Message**.
2. Press  up or down to select **Sent**. A list of all failed or pending messages appears.




3. Scroll through the list of messages and press  to read one. One of the following symbols appears next to each message:




The message is pending and will be sent when possible. You can cancel delivery of the message.



The message failed delivery.



4. You can choose to press  to Erase the message, press  to RESEND the message, or press  to choose other options. Options vary for Text, PIX, or Sound messages:
- **Play Again** replays the sound.
 - **Forward** allows you to send the message to another recipient.
 - **Erase** select to erase the message.
 - **Lock** select to lock or unlock the message.
 - **Save Quick Text** allows you to save the message as QuickText.
 - **Add to Contacts** allows you to add the number to your contact directory.
 - **Message Info** displays message information.

Retrieving text messages

When a text message is received the screen displays “NEW TXT MESSAGE” with the  symbol at the top of your screen. The symbol flashes if the message is urgent.



If you see the “New TXT Messages” note

Select an option:





- To view the message, press  to select **View now**.
- To view the message later, highlight **View Later** and press .

Note: If you receive a new message while you are reading a message, the one you are reading will be replaced by the new one.

You can find the older message in the **InBox**:


1. Press  to select **Message**.
2. Press  up or down to select **Inbox**.

If you see the symbol



1. Press  to select **Message**.
2. Press  up or down to select **Inbox**.
A list of all your received messages appears.
 -  indicates an “Urgent” message.
3. Scroll through the list of messages and press  to open one.


Reading the message

The options available to you may vary. Check with Verizon Wireless.

1. If the text message is long, press  down to view the entire message.

Note: Message length is limited by Verizon Wireless. An incoming message that exceeds the limit may be truncated.

2. When you are finished, you can press  to **Reply** to the sender or press  to select additional **Options**:
 - **Forward** the message.
 - **Reply wCopy** to reply to the message with a copy of the original attached.
 - **Save QuickText** to save the message as QuickText, which you can insert into other messages. Graphics and sound are not saved as part of QuickText. (For more about QuickText, see page 28.)
 - **Lock** to protect the message from being accidentally deleted.
 - **Add to Contacts** allows you to add the number to your contact directory.
 - **Message Info** view sender information.

Note: The  symbol indicates that a graphic did not come through. It may be too large or incorrectly formatted.

Setting message alerts


You can set your phone to alert you of incoming text messages or pages. For more information, see “Setting message alerts” on page 35.

Erasing messages






It is a good idea to erase old messages to free up memory in your phone.

You have the option of erasing text messages and pages as you send or read them, erasing them one at a time from the list in the Sent, Drafts, InBox, or erasing them all at once.

Erasing single messages



After you open a message you can choose to erase it. Press  to select **Erase**.

To erase messages from the **InBox**, **Sent**, or **Drafts** folder:

1. Press  to select **Message**.
2. Press  up or down to select the type of message you want to erase **InBox**, **Sent**, or **Drafts** and press .
3. Highlight the message and press  to select **Erase**. A message appears: “ERASE MESSAGE?”
4. Select **Yes** and press  to erase the message.




Note: You can erase a scheduled message from the **Sent** folder, but you cannot cancel delivery of the message.

Erasing all messages

1. Press  to select **Message**.
2. Press  to select **Options**.
3. Select a folder from which to erase all messages: **Erase InBox**, **Erase Drafts**, **Erase Sent**, or **Erase All Messages**. To erase messages from all folders, select **Erase All**.
4. A message appears: “ERASE ALL MESSAGES?” Select **Yes** to erase messages or **No** to cancel.



Erasing messages automatically






Use this setting to have old messages automatically erased from the **InBox** when memory is low.


1. Press  to select **Message**.
2. Press  to select **Settings**.
3. Press  to select **All Msgs**. → **Auto Erase** → **On**. Older messages will be erased as new messages are received.

Creating and editing prewritten messages (QuickText)

Your phone comes with prewritten (QuickText) messages, such as “Please call me,” which you can insert into the body of a text message. You can edit these messages and create new ones. Your phone will store up to 40 QuickText messages, with up to 100 characters per message.

1. Press  to select **Message**.
2. Press  to select **Settings**.

3. Press  to select **All Msgs**.
4. Press  up or down to select **Quick Text**.
5. Highlight a QuickText and select an option:
 - Press  to select **Erase**.
 - Press  to **Edit** an existing pre-written message.
 - Press  to select **New** and create a new pre-written message.

Note: To change text mode press  to select **Abc**. For additional help entering text, see “Understanding text entry screens” on page 14.





6. Press  to select **Save**.





Note: You can also save a message you have written or received as QuickText. See “Setting sending options” on page 23 or “Reading the message” on page 27.

Sending multimedia messages



You can only send multimedia messages to and from phones that are capable of receiving them or to email addresses. For details on availability, check with your service provider. Size limits may apply to multimedia message files. Contact your service provider for details.


Creating a PIX message

1. Press  to select **Message**.
2. Press  up or down to select **New Msg** → **PIX Msg**.
3. Enter a recipient's phone number or email address. Add another recipient if desired. Press  down to access the next recipient field. When you have finished adding the recipients press .







Tip: To add recipients **From Contacts**, **Recent Calls**, or **Groups** folders press  to select **Add**. Select an option and highlight a contact. Press  to select **Mark** or press  to select **Mark All**. When you have finished adding the recipients press  to select **Done**.




Note: You can send one multimedia message to a maximum of 10 contacts.


4. Press  down once to enter a brief text message in the **Text** field.
5. Press  up or down to select **PIX** field.

6. Press  to select **My PIX**.








You can choose to take a picture or select a picture from the **MY PIX** folder.

- To select a picture from the **MY PIX** folder, press  left, right, up, or down to highlight a **PIX** and then press  to select **View**. Press  to select it.
- To take a picture, press  to select **Camera**, press  to select **Take** to take the picture, and then press  to **Select** it.

Note: To remove the picture from your message, press  to select **Options**. Press  up or down to select **Remove PIX** and then press .







7. Press  to select **Send** to send your message. See “Setting sending options” on page 23 for information about how and when you want the message to be received.

Adding sound to PIX Message

1. Create a PIX message.
2. Press  up or down to select the **Sound** field.
3. Press  to select **Sounds**. Select an option:
 - Press  to select **Record New**, follow the prompts to record a message and press  to select it.
 - Press  up or down to highlight a sound, press  to select play to hear the sound you selected. Press  to select it.

Sending messages from contact lists





You can only send TXT and PIX messages to phones that are capable of receiving them or to email addresses.

1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Press  up or down to select **Contact List** or **Groups** and press .
3. Highlight a contact and press  to select **Options**.
4. Select **Send Txt Msg** or **Send PIX Msg** and press .
5. Select the fields where you want to enter Text, PIX, or Sounds and press  to select **Send**.

Auto receive mode

When a multimedia message is received, it is automatically downloaded onto your phone.

The alert “Receiving Message(s)” appears followed by “Message Received. View now?”


1. Press  to select **Message**.
2. Press  to select **Settings**.
3. Select **PIX Msg** and press .
4. Press  to select **Auto Receive**.
 - **ON** downloads messages automatically from the server.
 - **OFF** will prompt you for download, when a Pix Alert is received.





Viewing multimedia messages

When you receive a multimedia message, a message appears on your phone's screen. The message is stored in the InBox until the full message is received.



If you see the “NEW PIX MSG”

Select an option:

- View the message, press  to select **View now**.
Note: If a multimedia message is received during a call, then the phone downloads the message approximately one minute after the last key is pressed.
- View the message later:

1. Highlight **View Later** and press .
2. From the home screen, press  to select **Message**.
3. Press  up or down to select **Inbox**.
4. Highlight the message you want to view and press  twice to select **OPEN** → **View now**.


You can choose to select options:

5. Press the right softkey  to select **Options**. Press  down to highlight additional options for the multimedia message:

Note: The options available to you may vary. Check with your service provider.

- **Forward** launches the message creation screen, allowing you to forward the multimedia message. The original address








is not shown, nor the graphic, sound, and text fields.

- **Save PIX** saves the currently viewed picture embedded in the multimedia message.
 - **Save Quick Text** saves the text in the multimedia message to the QuickText list.
 - **Lock Msg** to avoid accidentally erasing it.
 - **Play Again** plays the multimedia message again from the beginning.
 - **Message Info** displays multimedia message information (priority, sender, subject, time sent and received, and message size).
 - **Mute** silences the embedded sounds in the multimedia message.
 - **Sender** displays sender information.
 - **Save Sound** saves the current sound embedded in the multimedia message.
 - **Save Address** extracts email addresses, phone numbers, and/or URLs from the sender information and multimedia message body.
 - **Save Message** saves the multimedia message to the Saved Folder on the phone.
6. When you are finished viewing the multimedia message, select **Reply** or press .

Tip: You can choose to **Reject** the message.




Sending contact information via TXT message

You can send contact information in your text message.

1. Press  to select **Menu**. This will take you to the Contacts menu.
2. Press  up or down to select **Contact List** or **Groups** and press .
3. Highlight a contact and press  to select **Options**.
4. Press  up or down to select **Send via TXT Msg** and press .
5. Follow the prompts, enter the message and press  to select **Send**.




Accessing Email

Selecting Email launches the browser for access to email.

- Press  to select **Message**. Press  up or down to highlight **Email** and then press . Follow the prompts.




Accessing Mobile IM

Selecting Mobile IM launches the BREW IM application on the Mobile IM screen.

- Press  to select **Message**. Press  up or down to highlight **Mobile IM** and then press . Follow the prompts.

Accessing Chat

Selecting Chat launches the browser for access to Chat.

- Press  to select **Message**. Press  up or down to highlight **Chat** and then press . Follow the prompts.

7 CUSTOMIZING YOUR PHONE

The contents of the **Settings & Tools** menu are as follows.

My Account

Tools

Voice Features

Calculator

Calendar

Alarm Clock

World Clock

Notepad

To Do List

Sounds Settings

Master Volume

Call Sounds

Alert Sounds

Keypad Volume

Earpiece Volume

Service Alerts

Power On/Off

Display Settings

Banner

Backlight

Contrast

Wallpaper

Screensaver

Display Themes

Dial Fonts

Clock Format

Power On/Off Anim.

Phone Settings

Standalone Mode

Shortcut Keys

Language

Security

System Select

NAM Selection

Headset Ringing

Call Settings

Answer Options

Auto Retry

TTY Mode

Hearing Aid

One Touch Dial

Voice Privacy

Restrict Calls

Data Settings

DTMF Tones

Fast Find

Bluetooth

Add New Device

Memory

Memory Usage

My PIX

My Sounds

Phone Info




My Number

SW Version

Icon Glossary

My Account




Connect to Verizon's web site to get quick and convenient access to your Verizon Wireless account. For more information, contact Verizon Wireless.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  to select **My Account**.

Silencing all sounds


Your phone is set to make sounds when you receive calls, press keys, navigate through menus, and receive alerts (such as new messages). You can silence all sounds and set the phone to vibrate when you receive calls and alerts.

Setting the phone to vibrate


1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sounds Settings** → **Call Sounds** → **Call Vibrate** → **On**.

Note: The phone will ring when it is attached to an external power source (such as a charger), even if all sounds have been silenced.

Shortcut to Vibrate Only mode










- Press and hold .

Turning sounds back on

- Press and hold .

Choosing ringers

Your Kyocera K323 phone has multiple ringers you can choose to use for incoming calls.




1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sounds Settings** → **Call Sounds** → **Call Ringtone**.
4. Select an option:
 - Press  to select **Get New Ringtones**. Press  again to select **Get New App**, and then follow the prompts to download ringtones.
 - Press  up or down to highlight a ringtone. Press  to select **Play** to hear the different ringtones and then press  again to select **Stop**.
5. Press  to select it.

Note: Downloaded ringtones are added to the end of the standard list of ringtones.

Setting sounds for your phone

You can set your phone to sound tones. Sounds will not occur during an incoming call, if you are in a call, or if a headset or hands-free car kit is attached to your phone.



Set sound when phone powers on or off

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sound Settings** → **Power On/Off**.
Select an option:
 - **Power On** sets sound when the phone powers on.
 - **Power Off** sets sound when the phone powers off.






Adjusting volume

You can adjust the earpiece, speakerphone, and ringer volume as well as key tones.






Adjusting the earpiece volume

To adjust the earpiece volume manually during a call, press  or .

To set the earpiece volume:





1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sounds Settings** → **Earpiece Volume**.
4. Press  to increase or decrease the volume and then press .



Adjusting the ringer volume

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sounds Settings** → **Master Volume**.
4. Press  up or down to increase or decrease the volume and then press  to select **Set**.

Adjusting key tone volume



You can change the volume of the tones the phone makes when you press the keys.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Sounds Settings** → **Keypad Volume**.
4. Press  to increase or decrease the volume.

Press  to increase or decrease the volume and then press .

Setting key length

You can change the duration of the tones the phone makes when you press the keys.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.






Using your phone in an airplane


While in an airplane, it is normally required that you turn off your mobile phone because it emits RF signals that interfere with air traffic control.

In **Standalone** mode, however, your phone will not emit RF signals. You cannot make or receive calls, send text messages, or use the Web, but you can play games, use the calendar, set the clock, and make emergency calls to designated emergency numbers.

Note: Please check with uniformed personnel before operating your phone in Standalone mode.





Setting Standalone mode

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Settings** → **Standalone Mode**.
 - On the Standalone Mode indicator will display in the Signal Strength area on the System Status Bar.
4. Press  up or down to select **ON**.
The display will read, "Do you want to set the date/time now?" Press  to select **Yes** to set the time, or **No** to continue.

Note: When standalone mode is enabled,  **OFF** is displayed on the phone's screen.

Choosing a different language





Your phone may display alternative languages.


1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Settings** → **Language**.
4. Select a language and press .

Personalizing the screen

Changing your banner

The banner is the personal label for your phone. It appears on the home screen above the time and date. The banner can be up to 14 characters long.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings** → **Banner**.
4. Press  to select **Personal**.
Enter your new text.





Press  to select **Save**.

- or -

Select **ERI Banner**, the ERI banner displays network information such as Verizon network and Roaming.






Adjusting the backlighting

Your screen lights up while you are in a call or when you press a key on the keypad. However, you can set the length of time that bright backlighting remains on.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings** → **Backlight**.
4. Select an option and press :
 - **7 seconds, 15 seconds, or 30 seconds**—(Default) Turn backlighting on for 7, 15, or 30 seconds after your last keypress.
 - **Always On, Always Off**—Turn backlighting on or off.








Note: The “Always On” setting drains the battery more quickly. The battery charges more slowly when backlighting is on.

Changing the display contrast

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings** → **Contrast**.
4. Press  left or right to adjust the contrast and press .







Selecting wallpaper


Wallpaper appears on the home screen.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings** → **Wallpaper**.
4. Highlight a wallpaper design and press  to view it or  to **Get New App** and download a Wallpaper.
5. Press  to select it.
6. Press  to return to the home screen and wait 10 seconds to view the wallpaper you chose.

Selecting a screen saver

Screen savers appear on the home screen when the flip is open or closed and are activated 10 seconds after the last keypress. Incoming calls and alerts override screen savers.












1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings** → **Screensaver**.
4. Highlight a screensaver design and press  to view it or  to **Get New App** and download a Screensaver.
5. Press  to select it.

6. Press  to return to the home screen and wait 10 seconds to view the screen saver you chose.

Note: Get New Apps downloaded screen savers are added to the end of the list.





Setting a PIX as Wallpaper, Screensaver, or Picture ID

You can set a picture that you have stored in your PIX folder as Wallpaper, a Screensaver, or as a contact's Picture ID.

1. Press  to select **Menu**.
2. Press  left or right to select **GET IT NOW**.
3. Press  up or down to select **Get PIX → My PIX**.
4. Press  up, down, left, or right to highlight a PIX and press  to select **View**.
5. Press  to select **Options**.
6. Press  up or down to select **Set As**.
7. Select an option and then press :
 - **Wallpaper** press  to set the selected picture as a Wallpaper.
 - **Screensaver** press  to set the selected picture as a Screensaver.
 - **Picture ID** select a contact and press  to assign the selected picture as a ID.






Selecting a color theme

You can select a color theme for the display background of your phone.




1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings → Display Themes**.
4. Scroll through the options to view the color themes and press  to select one.




Setting dial fonts to large

The keypad numbers you view when dialing can be changed to a larger size.





1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings → Dial Fonts**.
4. Press  to select **Large** and press .

Choosing a different time/date format

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Display Settings → Clock Format**.
4. Select an option **Digital** or **Analog**.

- Press  to select a **Format** and press  to save your changes.
 - 12 hour format
 - 24 hour format
- Press  to save your settings.

Power On/Off Animation



- Press  to select **Menu**.
- Press  left or right to select **Settings & Tools**.
- Press  up or down to select **Display Settings** → **Power On/Off Anim.**
- Select an option and press .
 - Animation 1**
 - Animation 2**




Creating a secure environment

This section describes all the features involved in securing your phone and preventing access to personal information. All security features are shielded by a four-digit lock code.



Locking your phone

When your phone is locked, you can call only emergency numbers or a Verizon Wireless number. You can still receive incoming calls.

- Press  to select **Menu**.
- Press  left or right to select **Settings & Tools**.





- Press  up or down to select **Phone Settings** → **Security**.
- Enter your four-digit lock code and press .
- Select **Lock Mode** → **Device**.
- Highlight an option:
 - Lock** locks the phone immediately.
 - Unlock** unlocks the phone.
 - On power up** locks the phone every time you turn it on.
- Press .

Unlocking the phone




- From the home screen, press  to select **Unlock**.
- Enter your four-digit lock code and then press .

Understanding roaming







Controlling network roaming

- Press  to select **Menu**.
- Press  left or right to select **Settings & Tools**.
- Press  up or down to select **Phone Settings** → **System Select.**
- Select an option and press .
 - Automatic A**
 - Automatic B**
 - No Roaming**

NAM Selection




1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Settings** → **NAM Selection**.
 - **NAM1**
 - **NAM2**



Restricting Calls

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Settings** → **Security**.
4. Enter your four-digit lock code and press .
5. Select **Restrict Calls**, and press .
6. Select **Code Enabled** and press .

Changing your lock code




The lock code is typically 0000 or the last 4 digits of your phone number.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Settings** → **Security**.

4. Enter your four-digit lock code and press .
5. Select **Edit Code**.
6. A message appears: “New Code????, Confirm Code????”
7. Enter a new four-digit code.
8. Enter your new lock code again and then press .







Voice Privacy

P will display on the screen indicating that Voice Privacy is active. The Voice Privacy indication on the screen only appears when a call is placed.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Call Settings** → **Voice Privacy** → **On**.

Erasing all contacts




You can erase all entries from your Contacts directory.


1. Press  to select **Menu**.
2. Press  left or right to select **Contacts**.
3. Press  up or down to select **Contact List**.
4. Press  to select **Options**.
5. Press  up or down to select **Erase All**. A message appears: “Erase ALL Contacts?”
6. Press  to select **Yes** to erase all contacts.

Data Settings

Setting Com port speed




The Com Speed sets the data rate at which your phone connects to a laptop or PC, or at which it sends and receives over-the-air text messages.

1. Connect the phone to the laptop or PC.
2. Set the Com speed.
3. Press  to select **Menu**.
4. Press  left or right to select **Settings & Tools**.
5. Press  up or down to select **Call Settings** → **Data Settings** → **Port Speed**.
6. Select the speed. The options are: **19.2 kbps**, **115.2 kbps** (default), **230.4 kbps**, and **Other**.

Note: There may be a higher charge for making calls using high-speed data in areas where  service is available. Check with Verizon Wireless for details.

Connecting to a TTY/TDD device






You can connect the phone to a TTY device for the hearing impaired. **Note:** Enable TTY only when using the phone with a TTY device.

1. Connect the TTY device to the phone.
2. Press  to select **Menu**.
3. Press  left or right to select **Settings & Tools**.
4. Press  up or down to select **Call Settings** → **TTY Mode**.

5. Select an option.
 - **TTY Full** turn on TTY.
 - **TTY Off** disable TTY Mode.

Connecting to a Hearing Aid device



You can connect the phone to a hearing aid device for the hearing impaired. **Note:** Enable Hearing Aid only when using the phone with a hearing aid device.



1. Connect the hearing aid device to the phone.
2. Press  to select **Menu**.
3. Press  left or right to select **Settings & Tools**.
4. Press  up or down to select **Call Settings** → **Hearing Aid**.
5. Press  up or down to select **On** and then press .

Setting position location







This setting allows you to share your location information with network services other than emergency services (For example: 911, 111, 999, and 000) in markets where service has been implemented.

Note: This feature works only when your phone is in digital mode. You do not have the option of turning off the locator to emergency services.





1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.

3. Press  up or down to select **Phone Settings** → **Security**.
4. Enter your four-digit lock code and press .
5. Select **Lock Mode** → **Location**.
6. Select **Location On** or **911 Only**.
 - **Location On** shares your position information with Verizon Wireless's network, in addition to emergency services.
 - **911 Only** (default) shares your position information only with emergency services when you call your 3-digit emergency code (911, 000, 111, etc.).




Bluetooth

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Bluetooth**.
4. Select an option:
 - Press  to select **Add New Device**.
 - Press  to select on or off.
 - Press  to select Settings:
 - **My Phone Name** personalize the name of the phone.
 - **Discovery Mode** On/Off.

Memory

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Memory**.
 - **Memory Usage** total memory used and available
 - **My PIX** and **My Sounds** file name and size. You can choose to erase the file. Scroll up or down to highlight the file, then press  to select **Erase**.





Phone Info

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Phone Info** and select an option.
 - **My Number** view your phone number.
 - **SW Version** view your phone's software information.
 - **Icon Glossary** view a list of the phone icons.




Tips before operating your camera

- You cannot activate the camera while on an active call or while browsing files in the media gallery.
- Once the camera is active, the home screen acts as the viewfinder.
- If you get a “Low memory” error, check your resolution and quality compression settings. See “Setting up the camera for photos” on this page.
- If there is no activity within 45 seconds after you turn your camera on, the camera quits and returns to the previous launch point.
- Menu settings and options can only be accessed when the camera is active.

Accessing camera mode

1. Open flip.
2. Press  - or -
1. Press  to select **Menu**.
2. Press  left or right to select **GET IT NOW**.
3. Press  up or down to select **Get PIX → Take PIX**.

Setting up the camera for photos

1. Open flip and press .
2. Press  to select **Options**.
3. Highlight an option and press :
 - **Resolution** options are 640 x 480, 320 x 240 (best for sending to email), and 160 x 120.
 - **Self Timer** options are Off (default) or 3, 5, or 10 second pauses. When set, the camera beeps from 3 seconds down to the time the shutter snaps the picture automatically. Self Timer is not available when **Multishot** mode is activated.
 - **Flash** options are Auto Flash, Off, On, or Only This Shot.
 - **Brightness** allows you to adjust the brightness of the image in the home screen LCD.
 - **White Balance** allows the camera to adjust for different lighting. Options are Auto, Sunny, Cloudy, Tungsten, Fluorescent, or Darkness.
 - **Shutter Sound** sets the sound used when the camera takes a picture.
 - **Color Effects** sets the color tone of the picture, Normal, Antique, Black and White, and negative.

- **Multishot** allows you to take up to six multiple pictures while the camera key is pressed and held. Options are Off or On. When set to ON, a tone will play each time a picture is taken.
- **Save Format** allows you to set the picture file format to JPEG or JIFF.

Restoring camera menu settings

The following settings **revert** to the default setting each time you enter and exit the camera application:






- Brightness, Self Timer, MultiShot.

The following settings **remain** at the setting you selected each time you enter and exit the camera application:


- Flash, Resolution, Shutter Sound, and White Balance.


Camera mode indicators and icons





The camera mode displays the following onscreen indicators and icons:

Icon	Description
	Flash on
	Camera mode
	Zoom level
Bottom right numbers	Resolution setting
	Multishot
	Self Timer






Taking a picture

1. Open flip.
2. Press 
 - or -
 - select **Menu** → **GET IT NOW** → **Get PIX** → **Take PIX**.
3. Focus on the image using the phone's display as the viewfinder.

Note: You can press  left or right to zoom in or zoom out if the phone's resolution settings are at 320 x 240 or 160 x 120 . When zoomed to maximum or minimum a tone plays.







4. Press  to select **Take**.
5. Press  to select **Save** or  to select **Erase**.
6. Press  when finished taking pictures.

Viewing a saved picture

1. Press  and then press  to select **My PIX**
- or -
select **Menu** → **GET IT NOW** → **Get PIX** → **My PIX**.
2. Press  to scroll through the pictures and press  to select **View**.
Press  for more options:
Note: Options vary depending on selected picture.
 - **Send** allows you to send a PIX message. see “Sending multimedia messages” on page 29.
 - **Get New PIX** accesses Get New App. see “Get PIX” on page 55.
 - **To PIX Place** allows you to connect to the browser to purchase and download new PIX.
 - **Set As** allows you to assign a picture as Wallpaper, Screen Saver, or assign a Picture ID to a contact see “Setting a PIX as Wallpaper, Screensaver, or Picture ID” on page 38.
 - **Rename** allows you to edit the name of a picture file.


- **Lock** allows you to lock or unlock a picture for editing. If a file is locked, you cannot erase, rename, or modify the file.
- **Erase** erases the selected picture.
- **Erase All** erases all camera PIXs.
- **PIX Info** allows you to view details of the picture.

Erasing saved pictures

1. Press  and then press  to select **My PIX**.
- or -
select **Menu** → **GET IT NOW** → **Get PIX** → **My PIX**.
2. Press  to highlight the picture you want to erase and press  to select **View**.
3. Press  to select **Options**.
4. Highlight **Erase** and press .
Note: To erase all camera PIX in your folder, select **Erase All**.

9 USING VOICE RECOGNITION









Voice recognition allows you to make and answer calls by speaking commands into the phone's microphone.

Note: You cannot use voice recognition to end a call; you must press  when the flip is open.

Setting up voice dialing


To make or receive calls using voice dialing, contacts must be saved with associated voice tags.

Creating a voice tag for a contact


1. Press  to select **Menu**. This will take you to the **Contacts** menu.
2. Select **Contact List** and press .
3. Select a contact and press  to select **View**.
4. Press  up or down to highlight the number.
5. Press  to select **Edit**.
6. Press  to select **Options**.
7. Highlight **Set Voice Dial** and press .
8. Follow the voice prompts. You will need to say the name twice.
9. Press  to select **Save**.

Making a call using voice tags









1. If you haven't already done so, record a voice tag for the person you wish to call.

2. With the flip open, from the home screen, press and hold . The phone responds: "Say a name or Say Dial."
3. Say the name of the person you want to call.
4. If the name you said matches a contact in the Voice Dial List, the phone responds: "Calling (Name)." Remain silent to make the call, or say **No** to cancel.

Note: If the phone finds multiple voice tags that sound like the name you said, you will be asked to verify which name you want to call. Say **Yes** when you hear the correct name. Say **No** when you hear an incorrect name.

5. When you are finished with the call, press  to end the call.


Removing a voice tag

1. Press  to select **Menu**. This will take you to the **Contacts** menu.
2. Select **Contact List** and press .
3. Select a contact and press  to select **View**.
4. Press  up or down to highlight the number.
5. Press  to select **Edit**.
6. Press  to select **Options**.
7. Highlight **Remove Voice Dial** and press  twice.
8. Press  to select **Save**.

Making a call using digit dialing

When using digit dialing, you speak digits to dial a phone number.

Note: You cannot speak a string of digits. You must speak one digit at a time and wait for the prompt.

1. From the home screen, press and hold . The phone responds: "Say a name or Say Dial."
2. Say "**Dial**". The phone responds: "Speak a digit."
3. Speak the first digit of the phone number you want to call. Once the phone repeats the digit, you can speak the next digit.

If you pause, the phone will prompt you with the following five options. After the prompt, speak an option.

- Say "**Clear**" to erase the last digit entered. The phone responds: "Digit cleared." To clear the entire phone number, say "**Clear**" again. When the phone prompts you with "Clear entire phone number?", say "**Yes**" to clear or "**No**" to cancel.
- Say "**Call**" to dial the number.
- Say "**Verify**" to cause phone to repeat the set of digits that you input.
- Say "**Cancel**" to exit voice recognizer and return to the home screen.

- Speak a digit to enter the next digit. Once the phone repeats the digit, you can speak the next digit or pause to hear the prompt.

Using voice features with hands-free car kits






You can use voice commands to make a phone call or to answer the phone only if your phone is connected to a professionally installed Kyocera hands-free car kit (sold separately).

Note: The following features apply only to installed hands-free car kits unless noted.

Waking up the phone

If your phone is connected to a Kyocera installed hands-free car kit, you can use the voice command to activate the phone to make a phone call.

To activate the Voice Wake-up setting:

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Voice Features** → **Voice Wake-Up**.
4. Press  down to select **Hands Free** and press .

To wake up the phone:

1. Say "**Wake Up**" and listen for a tone.
2. Say "**Wake Up**" again until you hear two tones.

If the phone does not recognize your “Wake up” command, see “Training voice recognition” on page 49.

Answering the phone




You can set your hands-free car kit to (1) answer automatically or (2) answer using a voice command.

Note: Headset or Car kit accessory must be attached.

Answering automatically

You can set your phone to answer automatically.

Note: This setting also works with the portable hands-free car kit.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Call Settings** → **Answer Options** → **Auto Answer**.





Answering using voice commands

If **Auto-Answer** is turned off, you can use a voice command to answer an incoming call using the installed hands-free car kit.

- Select **Menu** → **Settings & Tools** → **Call Settings** → **Answer Options** → **Flip Open**.


To activate the Voice Answer setting:

Note: The accessory must be attached to use this feature.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Voice Features** → **Voice Answer**.
4. Highlight **Enabled** and press .


To answer a call:

When you receive an incoming call, the phone responds: “Incoming call, answer?” or “Incoming roam call, answer?” If the caller is recognized as a contact entry in your phone, then the phone will say “Incoming call from (Name), answer?”




- Say “**Yes**” or press any key except .

Ignoring an incoming call

To ignore an incoming call, do one of the following:




- Say “**No**” and press  to silence the alert.
- Remain silent. The voice alert repeats twice and the phone rings once, then returns to the home screen.

Voice Prompt Mode

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Voice Features**.
 - **Prompt Mode** reads out prompts to the user.
 - **Tones Only** prompts the user with a tone.

Training voice recognition








If your phone is having trouble recognizing your voice, you can train it with the commands **Yes**, **No**, and **Wake up**.


1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Voice Features** → **Voice Training**.
4. Select **Train All** or the item you want to train.
5. Follow the prompts for each word until training is complete.



10 USING TOOLS

Calculator

Use the calculator for basic mathematical equations.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Calculator**.
4. Use the keypad to enter numbers.
5. Use  to select mathematical operations:
Left ÷ (divide) **Right** x (multiply)
Up + (add) **Down** - (subtract)
6. Press  to calculate the result.
Example: Enter 5, press  right to select X, enter 2, then press  to obtain the result of 10.

To enter (,) or ?, press  to select **Options**.

7. Press  to return to the home screen.
- or -
Press  to clear the screen.











Additional options, from the keypad

























- Press *
- ± Press #
- = Press OK






Calendar

The Calendar allows you to schedule events and set reminder alerts.













Creating an event



1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Calendar**.
4. Press  to select **Options** and press  .
 - **Go to Today** selects today's date on the calendar.
 - **Go to Date** allows you to go to a date on the calendar you specify.
 - **Convert Calendar** allows you to set the calendar to PDT time.
5. Press  to select **Add new**.
6. Enter a name for the event and press  down. For help entering text, see page 14.
7. Press  to select **Edit**. Set the **Start Date** of the event (the current date is the default date of the event).
 - Press  left or right to move between the month, day, and year fields.
 - Press  up or down to change the month, day, or year.

- Press  to save your changes.
8. Press  down to highlight **End Date**. Press  to select **Edit**.
- Press  left or right to move between the month, day, and year fields.
 - Press  up or down to change the month, day, or year.
- Press  to save your changes.
9. Press  down to highlight **Start Time**. Press  to select **Edit**.
- Press  left or right to move between the hour, minute, and AM/PM fields.
 - Press  up or down to change the hour, minute, or AM/PM.
- Press  to save your changes.
10. Press  down to highlight **End Time**. Press  to select **Edit**.
- Press  left or right to move between the hour, minute, and AM/PM fields.
 - Press  up or down to change the hour, minute, or AM/PM.
- Press  to save your changes.
11. Press  down to highlight **Time Zone**. Press  to select **Edit**. Press  to select an option. Press  to save your changes.
12. Press  down to highlight **Recurrence**. Press  to select **Edit**. Highlight an option and press  to select it. Press  to save your changes.

13. Press  down to highlight **Alert**. Press  to select **Edit**. Highlight an option and press  to select it.
- **Tone** you can press  to select **Play** to hear the sound of the Tone Alert.
 - **Vibrate** sets the alert to vibrate.
 - **Reminder** allows the phone to remind Once, Every 2 minutes, or Every 15 minutes.
- Press  to save your changes.

Editing or erasing an event

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Calendar**.
4. Go to the date of the event and press .
5. Select an option to erase or edit the event:
 - To erase the event, press  to select **Options** and then press  to select **Erase**. Press  up or down to select **Yes** and then press .
 - To edit the event, press  to select **View** and continue to step 6.
6. Press  to select **Edit**.
7. Press  up or down to select the option you want to edit.
8. Press  to select **Edit**.
















9. Press  to save your changes.
10. Press  again to save the event.

Alarm Clock


You can set up to four alerts with your phone's three alarm clock.


Note: The alert occurs only if the phone is on.


Setting an alarm clock


1. Press  to select **Menu**.
 2. Press  left or right to select **Settings & Tools**.
 3. Press  up or down to select **Tools** → **Alarm Clock**.
 4. Highlight one of the alarms and press .
 5. Press  to select **Set**.
 6. Press  up or down to select **On**.
 7. Press  down to highlight **Time**.
 8. Use the phone keypad to enter numbers and  or to switch between AM and PM.
 - Press  left or right to move between hours, minutes, and AM/PM fields.
 - Press  up or down to change the hours, minutes, and AM/PM options.
- Press  to set the time of the alarm.
- Press  to save.
9. Press  down to highlight **Frequency**.
- Press  to select **Set**.
- Highlight an option and press .



Press  to save.

10. Press  down to highlight **Ringer**.

Press  to select **Set**.




Highlight a ringer and press .

Note: You can press  to select **Play** to hear the sound of the Ringer.

11. Press  to save.
 12. When the alarm rings, select **Snooze** to silence the alarm for 10 minutes or **Dismiss** to turn off the alarm and then press .
- Note:** Opening the flip turns off the alarm.




World Clock

The World Clock lets you check times in cities around the world in relation to local time.






1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **World Clock**.




The World Clock menu is displayed. Your local time and date is on the first line, followed by your selected world city and that city's time and date.

When you first access World Clock, you are prompted to select a city.

4. Press  to select **Cities**. The Cities menu is displayed, showing 85 world cities in alphabetical order.
5. Press  up or down to scroll through the cities list. You can also use the number keys (2-9) to alphabetically tab through the list.
6. Press  to select a city, like Athens. The World Clock menu is displayed again, with Athens' time and date.




From the World Clock menu, you can also select **Edit** to search by city or country.

1. Select **Edit** from the World Clock menu. The Edit City menu is displayed.
2. Select your type of search.
 - Press  search **By City**.
 - Press  down, then press  to search **By Country**.
3. If you search by City, the Search screen is displayed.
 - a. Use your number keys (2-9) to enter the letter(s) by which you want to search. For example, press **2** once to enter the letter **A**.
 - b. Press **Ok**.
 - c. Cities beginning with A are displayed, like Anchorage, Athens, and Atlanta.
 - d. Use  to move through the list, press  to view information on the city you highlighted




- e. Press  to select a city.
4. If you search by Country, the Find Country screen is displayed.
 - a. Use your number keys (2-9) to enter the letter(s) by which you want to search. For example, press **2** once to enter the letter **A**.
 - b. Press **Search**.
 - c. Countries beginning with A are displayed, like Afghanistan, Algeria, and Australia.
 5. Use  to move through the list, then press  to select a country.

Notepad

Use to enter notes. The first line of the note becomes the title of the note.

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **Notepad**.







Select an option and follow the prompts.


- Highlight a note and press  to view or edit it.
- Press  to select **Add New**.
- Press  to select **Erase**.

To Do List








Allows you to manage personal or work-related assignments. To Do List application allows you to create, store, retrieve task records, set due date and alert reminders associated with those tasks.

Create a task

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **To Do List**.
4. Press  to select **Add New**.
5. Press  up or down to access and then enter the information in the appropriate fields:
 - **Task Name** allows you to name the task.
 - **Status** set the status.
 - **Priority** set the priority level.
 - **Date** set the date of the task.
 - **Time** set the time the task will take place.
 - **Reminder** sets an alert to remind you of the task.
 - **Reminder Sound** allows you to select the sound of the reminder alert.
 - **Notes** allows you to enter notes.
6. Press  to select **Set** after completing each field.

7. Press  to select **SAVE** to save the new task.

Edit a task

1. Press  to select **Menu**.
2. Press  left or right to select **Settings & Tools**.
3. Press  up or down to select **Tools** → **To Do List**.
4. Highlight a task and press  .
 - Edit, press  .
 - View, press  .
 - Options, press  .

11 GET IT NOW

About Get It Now®

Your Kyocera phone from Verizon has the ability to download and manage applications through Get It Now.

Get It Now brings you the full range of applications and services you have come to expect from the Internet, including games, ringtones, and much more.





How does Get It Now work?

You connect to the server, download applications, and then manage them as you like. When you choose an application, you may choose a demo (not available for all applications), various limited use options, or the full version—all varying in price. If you choose a demo, Get It Now lets you know when it has expired. If you choose a priced version, the amount is added to your phone bill. Get It Now also lets you know if you're running out of memory. At that point, you can either disable an application or remove it completely.

Once applications are loaded, you can update to newer versions as they become available.

Downloading an application

Downloaded applications are stored under the Get It Now menu. Each application comes with its own unique icon, to help you identify it easily.

1. Press  to select **Menu**.
2. Press  left or right to select **GET IT NOW**.
3. Press  up or down to select an option.
4. Press  up or down to select **Get New App**.

Follow the on screen prompts to purchase and download your selection.

Get Tunes & Tones

- **Get New Ringtones** initiates a connection to download and purchase new ringtones.
- **My Ringtones** lists the ringtones available in your phone. Selecting **Get New Ringtones** → **Get New App** initiates a connection to download and purchase new ringtones.
- **My Sounds** lists the sounds available in your phone. Selecting **Record New** allows you to record a memo.

Get PIX

- **Get PIX** → **Get New PIX** initiates a connection to download and purchase new PIX.

- **My PIX** allows you to view a picture or select other options, see “Using the Camera” on page 43.
- **PIX Place** initiates a connection to
- **Take PIX** allows you to take a picture and set camera options, see “Using the Camera” on page 43.





Get Fun & Games, Get News & Info, Get Going, and Get Extras

- **Get New App** initiates a connection to purchase and download applications.

Note: The application is downloaded to your phone. Download times vary.

Info






You can get help with Apps, information about memory usage, the size of an App, and how many uses it has left before it runs out. You can also check on the overall memory usage of your applications and your content to help you decide whether you have space to download a new app or if you need to disable one to create space.

1. Press  to select **Menu**.
2. Press  left or right to select **GET IT NOW**.
3. Press  to select **Info**.
4. Press  up or down to select an option:
 - **Application Memory** displays the Application memory usage.

- **Content Memory** displays the Content memory usage.
- **View Log** displays the activity log.
- **Help** displays the Help list.

Removing an application


Important: If you remove an application, it is removed completely from your phone. If you want to use it again, you must pay for it again. If you want to free up space on your phone, we recommend you disable the application (see next section).

1. Press  to select **Menu**.
2. Press  left or right to select **GET IT NOW**.
3. Press  up or down to find and select the application you want to erase.
4. Highlight the downloaded application and press  to select **Options**.
5. Press  up or down to select **Erase**.
 - **Yes** erases the application
 - **No** cancels the erase selection

Note: Other options are **View Properties**, **Lock**, and **Upgrade Check**.

12 USING BLUETOOTH® WIRELESS TECHNOLOGY





The Bluetooth wireless technology on your K323 phone enables wireless connectivity with accessories such as wireless headsets, handsfree car kits, serial port, dial up networking, and the object exchange push profile for V-Card.


Note: You must use a Bluetooth wireless technology device (compatible with Class 2 Bluetooth wireless technology, version 1.2) in order to use this phone wirelessly. Bluetooth wireless technology accessories have the  symbol. For car kit and accessory compatibility go to www.verizonwireless.com/bluetoothchart.

Pairing the phone and device

You must “pair” your phone with the Bluetooth wireless technology enabled device to enable your phone to communicate with it. Refer to the instructions for setting up Bluetooth wireless technology (below) in conjunction with the user guide provided with your Bluetooth wireless technology device(s).

First time setup

1. Press  to select **Menu**.
2. Press  right twice to select **Settings & Tools**.
3. Scroll  down to select **Bluetooth** and press .




4. Press  to turn Bluetooth **On**. The message “Bluetooth set to on” displays.

Note: Once you turn Bluetooth on, the lower left corner displays the word **On**.




Add New Device


When you turn Bluetooth **On**, “Add New Device?” displays on the screen.

Follow these steps to have your phone detect available wireless devices:

1. Press  to select **Add New Device**.
Note: If Bluetooth is not **On**, the message “Turn Bluetooth On?” displays.
— Press  to select **Yes**.
2. If your wireless device is not already in pairing (or “discoverable”) mode do so now and press . (Check the device’s instructions.)




Note: All wireless devices in the vicinity will be detected regardless of whether they are compatible with your phone or not.

3. Once the desired wireless device has been detected, you can stop the discovery process by pressing . You may also let the phone continue finding all available wireless devices.
Note: If multiple devices are discovered, all are listed.
4. Use  to highlight the device you wish to pair and press  to select **Pair**.

5. Enter the password (passkey) provided with the wireless accessory as provided in its user guide or instructions and press  again.

Connect to the device


“Waiting for <device name> to connect” displays. Once the connection is ready, you must grant “permission” for the wireless device to pair with your phone.



1. Press  to highlight an option:
 - **Always Ask**
 - **Always Connect**
2. Press . “<device name> pairing complete” displays.
3. In order to connect the phone to the device now, press  to select **Yes** at the “CONNECT TO <DEVICE NAME>” prompt.

A message tells you that the device is connecting and then, that it has been successfully connected. You are now ready to use the Bluetooth enabled wireless device.



Allow other Bluetooth enabled wireless devices to discover your K323 phone

If you would like to have your wireless device(s) find your phone to enable pairing, set your phone to be “available”.

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Press  to select **Settings**.




3. Scroll down to select **Discovery Mode** and press .
4. Select **On** and press .


Note: The phone will stay in discovery mode for 1 minute.

5. Set the device to pairing mode according to the device’s user guide. “<DEVICE NAME> REQUESTS TO CONNECT” displays.
6. Select **Accept** or **Reject** and press .
7. Enter the password (passkey) provided with the wireless device as provided in its user guide or instructions and press  again.
8. Continue with pairing (page 57) and connecting the wireless device (below).

Connecting to a wireless device

Before you can use the wireless functions of your phone, you must set your phone to be ready to communicate with a wireless device. This is called “connecting.”

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Scroll to the wireless device and press  to select it. “Connect to <device name>” displays.
3. Press .
4. “TURN BLUETOOTH ON?” displays on the screen
5. Press  to select **Yes**.




6. A message on the phone tells you that your phone is connecting to <wireless device>.  will appear on the top row when a headset or HFK is connected.
7. You are now ready to use the wireless device with your phone.

Turning Bluetooth Off

Setting **Bluetooth** to **Off** prevents your phone from being used with any Bluetooth wireless technology device. To prolong battery life, it is recommended to set **Bluetooth** to **Off** when you are not using it.

Removing a wireless device




You can delete a wireless device from your K323 phone if you will not be using it any longer:

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Scroll to the device and press the right softkey  to select **Options**.
3. Scroll down to **Remove Device** and press . “Remove Device?” displays.
4. Select **Yes** and press .

Renaming a wireless device



Once you have paired a wireless device with your phone, you can rename it for easy identification.

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.

2. Scroll to the device and press the right softkey  to select **Options**.
3. Scroll down to **Rename Device** and press .
4. Enter a new name for the device and press .


Renaming your phone for identification by other wireless devices


You can change the name of the Bluetooth wireless technology device in your K323 phone as follows:

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Select **Settings** → **My Phone name** and press .
3. Enter the new name in the text field and press  to set the new name.

Keeping your phone secure


You may set a specific wireless device to be automatically connected when you pair it, or you can chose to have it require your permission to connect.

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Scroll to the device and press the right softkey  to select **Options** → **Incoming security**.
3. Select **Always Ask** or **Always Connect**.

4. Press  to confirm and return to the Bluetooth menu.

Wireless device Information

To view details about wireless devices which have been paired with your phone:

1. Select **Menu** → **Settings & Tools** → **Bluetooth** as described in “First time setup” on page 57.
2. Scroll to the device and press the right softkey  to select **Options** → **Device Info**.
3. You can see the **Type** of device, its **Status** (Connected or Not Connected), **Security** (Always Connect or Always Ask), the device's **Address**, the **Pairing Date**, and the **Last Connection** date.







13 CONNECTING TO THE INTERNET


Using the Web Browser

You can use your phone to browse the Internet if you have obtained phone Internet services from Verizon Wireless and if over-the-air Internet access is available in your area. A message displays "For Wireless Internet Services, please dial*611" if you have not yet obtained service.

Note: You cannot receive incoming calls while you are using Web Browser.

Launching the Web Browser

1. Press  up to access Mobile Web or select **MENU** → **GET IT NOW** → **Get News & Info**. If this is the first time you have connected to the Internet, a message informs you that security is not yet enabled for your Web Browser.
2. Press  to select **Yes** to enable security. When you are connected, a browser home page appears. It has a list of Web menu options.
 - A  appears in a secure session.
 - An underline and an arrow indicate that there is more text. Press  down to view more text. Press  to return to the previous screen.
 - To choose a site, highlight it and press  to select **Go**.

3. When you have finished using the Internet, press  to exit the Web Browser.

Web menu options



The following options may appear on your screen:

- **SEARCH** browse wireless websites, access content by category.
- **FAVS** displays a list of your saved Web sites.
- **HOME** returns you to the main Web Browser window, or home page.

Searching for a Web site

How you search for a Web site depends on Verizon Wireless. For more information, contact Verizon Wireless.

Going to a bookmarked site

1. Press  up to access Mobile Web or select **MENU** → **GET IT NOW** → **Get News & Info**.
2. From your Web home page, select **FAVS**. A list of bookmarks appears.
3. Enter the number corresponding to the bookmark you want and press .

Checking Net alerts

Alerts received from a Web site are sent to your Inbox.

1. Select **Menu** → **Messages** → **Inbox**.
2. Select an alert and follow the prompts.

Customer support

Verizon Wireless's customer support department may be accessible directly from your phone when you dial a number such as *611. They can answer questions about your phone, phone bill, call coverage area, and specific features available to you, such as call forwarding or voicemail.

For questions about the phone features, refer to the materials provided with your phone, or visit www.verizonwireless.com.

Before requesting support, please try to reproduce and isolate the problem. When you contact the Customer Care Center, be ready to provide the following information:

- The actual error message or problem you are experiencing.
- The steps you took to reproduce the problem.
- The phone's electronic serial number (ESN).
 - To locate the ESN select **Menu** → **Settings & Tools** → **Phone Info** → **SW Version** and scroll down to ESN: for the 11-digit number.

Qualified service

If the problem with your phone persists, return the phone with all accessories and packaging to the dealer for qualified service.

Phone accessories

Contact Verizon Wireless, or call 800-349-4188 (U.S.A. only), 858-882-1410, or visit www.verizonwireless.com.

Become a product evaluator

To participate in the testing and evaluation of Kyocera Wireless Corp. products, including cellular or PCS phones, visit beta.kyocera-wireless.com.

15 WARRANTY

Kyocera Wireless Corp. (“KYOCERA”) offers you a limited warranty that the enclosed product or products (the “Product”) will be free from defects in material and workmanship for a period that expires one year from the date of sale of the Product to you, provided that you are the original end-user purchaser of the Product and provided that your purchase was made from an authorized supplier. Transfer or resale of a Product will automatically terminate warranty coverage with respect to that Product. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Product.

KYOCERA shall, at its sole and absolute discretion, either repair or replace a Product (which unit may use refurbished parts of similar quality and functionality) if found by KYOCERA to be defective in material or workmanship, or if KYOCERA determines that it is unable to repair or replace such Product, KYOCERA shall refund the purchase price for such Product, provided that the subject Product (i) is returned, with transportation prepaid, to a KYOCERA authorized service center within the one year warranty period, and (ii) is accompanied by a proof of purchase in the form of a bill of sale or receipted invoice which evidences that the subject Product is within the one year warranty period (“Proof of Purchase”). After the one year warranty period, you must pay all shipping, parts and labor charges.

This limited warranty does not cover and is void with respect to the following: (i) any Product which has been improperly installed, repaired, maintained or modified; (ii) any Product which has been subjected to misuse (including any Product used in conjunction with hardware electrically or

mechanically incompatible or used with accessories not approved by KYOCERA), abuse, accident, physical damage, abnormal operation, improper handling, neglect, exposure to fire, water or excessive moisture or dampness or extreme changes in climate or temperature; (iii) any Product operated outside published maximum ratings; (iv) cosmetic damage; (v) any Product on which warranty stickers or Product serial numbers have been removed, altered, or rendered illegible; (vi) cost of installation, removal or reinstallation; (vii) signal reception problems (unless caused by defects in material and workmanship); (viii) damage the result of fire, flood, acts of God or other acts which are not the fault of KYOCERA and which the Product is not specified to tolerate, including damage caused by mishandling, shipping and blown fuses; (ix) consumables (such as fuses);

or (x) any Product which has been opened, repaired, modified or altered by anyone other than KYOCERA or a KYOCERA authorized service center. **USE ONLY KYOCERA APPROVED ACCESSORIES WITH KYOCERA PHONES. USE OF ANY UNAUTHORIZED ACCESSORIES MAY BE DANGEROUS AND WILL INVALIDATE THE PHONE WARRANTY IF SAID ACCESSORIES CAUSE DAMAGE OR A DEFECT TO THE PHONE.**

KYOCERA SPECIFICALLY DISCLAIMS LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, PUNITIVE, EXEMPLARY, AGGRAVATED, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF, WHETHER FORESEEABLE OR UNFORESEEABLE OF ANY KIND WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, UNANTICIPATED BENEFITS OR

REVENUE, ANTICIPATED PROFITS ARISING OUT OF USE OF OR INABILITY TO USE ANY PRODUCT (FOR EXAMPLE, WASTED AIRTIME CHARGES DUE TO THE MALFUNCTION OF A PRODUCT) OR CONTRIBUTION OR INDEMNITY IN RESPECT OF ANY CLAIM RELATED TO A PRODUCT.

REPAIR OR REPLACEMENT OF A DEFECTIVE PRODUCT OR REFUND OF THE PURCHASE PRICE RELATING TO A DEFECTIVE PRODUCT, AS PROVIDED UNDER THIS WARRANTY, ARE YOUR SOLE AND EXCLUSIVE REMEDIES FOR BREACH OF THE LIMITED WARRANTY, AND SUBJECT TO THIS WARRANTY, THE PRODUCTS ARE APPROVED AND ACCEPTED BY YOU "AS IS". KYOCERA MAKES NO OTHER WARRANTIES, REPRESENTATIONS OR CONDITIONS OF ANY KIND, ORAL OR VERBAL, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, WITH RESPECT TO THE PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. NO DEALER, DISTRIBUTOR, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION OR ADDITION TO THIS WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This limited warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction.

For warranty service information, please call the following telephone number from anywhere in the continental United States and Canada:

1-800-349-4478 or 858-882-1401; or contact KYOCERA at the following address:

10300 Campus Point Drive, San Diego, California, 92121-1582, USA, Attention: Technical Support.

DO NOT RETURN YOUR PRODUCTS TO THE ABOVE ADDRESS. Please call or write for the location of the Kyocera Wireless Corp. authorized service center nearest you and for procedures for obtaining warranty service.

INDEX

Numerics

1-touch dialing, 11

A

accessories, 62

alarm clock, 7, 52

alerts

for headsets, 35

for messages, 35

auto Save, 25

B

banner, 36

battery, 1

bluetooth wireless technology

connecting, 58

first time setup, 57

pairing, 57

removing wireless device,
59

renaming wireless device,
59

renaming your phone, 59

C

calculator, 50

call counters, 13

callback number, 24

calls

answering, 8

missed, 10

redialing, 9

camera

setting up, 44

taking a picture, 44

color themes, 38

com port speed, 41

contacts directory, 17

D

digital mode, 7

E

emergency

calls, 12

emergency mode, 12

exit emergency mode, 13

entry mode, 15

erasing

contact entries, 20, 40

text messages, 27

F

fast find, 21

finding contact information, 20

G

Get It Now, 55

H

hands-free car kit

answering using voice, 48

purchasing, 62

hands-free headset

and phone ringer, 35

jack, 4

purchasing, 62

I

icons, 7

messages, 26

recent calls, 10

K

key descriptions, 3

L

language, 36

lights

lights-only mode, 33

location

emergency, 7

on, 7

setting, 41

lock code, 40

locking your phone, 39

M

memory, 42

O

outbox, 25

P

phone

number verify, 6

unlocking, 39

Q

quicktext, 28

R

resetting the phone, iii

ringers

choosing types, 33

for contacts, 18

volume, 34

roaming, 7

controlling, 39

S

scheduler, 50

screen icons, 7, 22, 26

screen savers, 37

- security, 39
- signature, 23
- silent mode, 7, 33
- speed dialing, 20
- symbol mode, 15

T

- technical support, 62
- text entry, 14
 - quick reference, 16
- text messages, 22
- time format, 38
- timing calls, 13
- TTY/TDD, 41

U

- unlocking the phone, 39

V

- vibrate, 7, 33
- voice answer, 48
- voice dialing, 46
- voicemail, 11, 12
 - setting up, 11
- volume
 - earpiece, 9, 34
 - key beep, 34
 - ringers, 34

W

- wallpaper, 37
- web browser, 61
- world clock, 52



Kyocera Wireless Corp.
10300 Campus Point Drive
San Diego, California 92121 USA
www.kyocera-wireless.com

82-N8865-1EN, Rev. 001