

For more information on how to use the phone, please go to <https://www.tcl.com/us> and download the complete user manual.

User guide.

TCL 10 5G UW

verizon[✓]

Note:

This is a user manual for TCL- 790S.

Table of Contents

Safety and use	5
Radio waves.....	13
Licenses.....	19
General information	23
1 Your mobile	26
1.1 Keys and connectors	26
1.2 Setting up your phone	29
1.3 Home screen.....	33
2 Text input.....	45
2.1 Using the on screen keyboard.....	45
2.2 Text editing.....	47
3 Call, Call log and Contacts.....	48
3.1 Call	48
3.2 Call log.....	54
3.3 Contacts.....	55
4 Messaging	62
4.1 Write a new message	62

4.2	Manage messages	63
5	Calendar and Clock	65
5.1	Calendar	65
5.2	Clock	67
6	Getting connected	70
6.1	Connecting to the internet	70
6.2	Connecting to a Bluetooth device	72
6.3	Connecting to a computer via USB	74
6.4	Sharing a mobile data connection.....	75
6.5	Connecting to virtual private networks.....	76
7	Multimedia applications	78
7.1	Camera.....	78
7.2	Viewing Photos or Videos.....	83
8	Others.....	85
8.1	Other applications	85
9	Google applications.....	86
9.1	Chrome	86
9.2	Gmail	86
9.3	Maps.....	87
9.4	YouTube.....	87
9.5	Drive	87
9.6	Play Store	88
9.7	YouTube Music.....	88
9.8	Play Movies & TV	89

9.9	Duo.....	89
10	Settings.....	90
10.1	Network & internet	90
10.2	Bluetooth & device connection.....	92
10.3	Display.....	94
10.4	NXTVISION	95
10.5	Home screen & wallpapers.....	96
10.6	Sound.....	97
10.7	Advanced features	98
10.8	Smart Manager	98
10.9	Security	99
10.10	Location.....	100
10.11	Privacy.....	100
10.12	Apps	100
10.13	Storage	101
10.14	Account.....	101
10.15	Digital Wellbeing & parental controls ...	101
10.16	Google	102
10.17	Accessibility.....	102
10.18	System updates.....	102
10.19	System	102
11	Making the most of your phone.....	105
11.1	FOTA Upgrade.....	105

12	Accessories	106
13	1 YEAR LIMITED WARRANTY	107
14	Troubleshooting	108
15	Specifications	117



www.sar-tick.com

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found in the **Radio waves** section.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 15 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your phone near your ear while the loudspeaker is in use.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Safety and use

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY

Given that studies show that using a phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their phone when the vehicle is not parked. Check the laws and regulations on the use of wireless phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

CONDITIONS OF USE

- You are advised to switch off the phone from time to time to optimize its performance.
- Remember to abide by local authority rules of mobile phone use on aircrafts.
- This phone is a unibody device, where the back cover and battery are not removable. Disassembly of the phone will void your warranty. Disassembling the phone can cause bodily injury if the battery is punctured.
- Always handle your phone with care and keep it in a clean and dust-free place.
- Do not allow your phone to be exposed to adverse weather or environmental conditions, such as moisture, humidity, rain, infiltration of liquids,

dust, sea air, etc. The manufacturer's recommended operating temperature range is 0C (32°F) to +40°C (104°F). At over 40°C (104°F), the legibility of the phone's display may be temporarily impaired.

- Do not open, dismantle, or attempt to repair your phone yourself.
- Do not drop, throw, or bend your phone.
- Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your phone model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.
- Your phone should not be disposed of in municipal waste. Please check local regulations for disposal of or search for a recycling solution in your area: <https://search.earth911.com/>.
- Remember to make backup copies or keep a written record of all important information stored on your phone.
- Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family

history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

- Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, orientation, or movements.

PRIVACY

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your phone regarding taking photographs and recording sounds with your phone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization has been obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your phone (including the carrier) disclaim any liability which may result from improper use of the phone.

BATTERY

Observe the following precautions:

- Do not attempt to open the back cover.
- Do not attempt to eject, replace, or open the battery.
- Do not puncture the back cover of your phone.
- Do not burn or dispose of your phone in household rubbish or store it at temperature above

60°C (140°F).

Phone and battery as a unibody device must be disposed of in accordance with locally applicable environmental regulations.



This symbol on your phone, the battery, and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these types of equipment;
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

In non-European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities. Instead they are to be taken to collection points for them to be recycled.

Battery Recycling

TCL partners with Call2Recycle® to offer a safe and convenient battery recycling program. For more information on our Battery Recycling Program, please visit the USA at <https://www.tclusa.com/mobile/accessibility-compliance/tcl-mobile-battery-recycling-program/>.

In the United States you may learn more about CTIA's Recycling Program at <http://www.gowireless-gogreen.org/>

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

CHARGERS:

Home A.C./ Travel chargers will operate within the temperature range of: 0°C (32°F) to 40°C (104°F).

The chargers designed for your phone meet the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country):

Travel charger: 9V2A QC3.0

Input: 100-240V, 50/60Hz, 500mA

Output: 5V,3A/9V,2A/12V,1.5A

Battery: 4500 mAh

Radio waves.....

THIS PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Innovation, Science and Economic Development Canada (ISED), is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the phone transmitting at its highest certified power level in all tested frequency bands.

This device is complied with SAR for general population / uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID:2ACCJN042

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone. Before a phone model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for this model phone when tested is 1.0 W/Kg for use at the ear and 1.0 W/Kg for use close to the body.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for RF exposure.

For body-worn operation, the phone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 15 mm from the body.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <http://www.ctia.org/>

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of phones. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep phones away from the head and body. Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected;
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service, they bear the following statement:

This phone complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference;
- This device must accept any interference received, including interference that may cause undesired operation.

Your phone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with a headset or usb data cable.

If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 15 mm away from the body.

Please note by using the device some of your personal data may be shared with the main device. It is under your own responsibility to protect your own personal data, not to share with it with any unauthorized devices or third party devices connected to yours. For products with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your product as a hotspot (where available), use network security. These precautions will help prevent unauthorized access to your device. Your product can store personal information in various

locations including a SIM card, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only.

Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example against unauthorized or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- The technical possibilities available;
- The costs for implementing the measures;
- The risks involved with the processing of the personal data, and;
- The sensitivity of the personal data processed.

You can access, review, and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us

directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

Licenses



microSD Logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Technology Holdings Limited. and its affiliates is under licence. Other trademarks and trade names are those of their respective owners.

T790S Bluetooth Declaration ID **D050487**



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

Google, the Google logo, Android, the Android logo, Google Search™, Google Maps™, Gmail™, YouTube, Google Play Store, and Hangouts™ are trademarks of Google Inc.

The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License (the text will show when you touch Google legal in **Settings > System > About phone > Legal information**).

You have purchased a product which uses the open source (<http://opensource.org/>) programs mtd, msdosfs, netfilter/iptables and initrd in object code and other open source programs licensed under the GNU General Public Licence and Apache Licence. You may download the source codes from <https://sourceforge.net/projects/tcl-mobile/files/>. The provision of the source code is free of charge from the internet.

US Information Concerning the Federal Communications Commission (“FCC”) Requirements for Hearing Aid Compatibility with Wireless Devices

When wireless devices are used near hearing devices (such as hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference, and wireless devices also vary in the amount of interference that they generate.

The wireless telephone industry has developed ratings to assist hearing device users in finding wireless devices that may be compatible with their hearing devices. Not all wireless devices have been rated. Wireless devices that are rated will have the rating displayed on the box together with other relevant approval markings.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device is vulnerable to interference, you may not be able to use a rated wireless device successfully. Consulting with your hearing health professional and testing the wireless device with your hearing device is the best way to evaluate it for your personal needs.

This smartphone has been tested and rated for use with hearing aids for some of the wireless technologies that the smartphone uses. However, other wireless technologies may be used in this smartphone that have not been tested for use with hearing aids. It is important to try the different features of your smartphone thoroughly and in different locations to determine if you hear any interfering noise when using this smartphone with your hearing aid or cochlear implant. Consult your wireless service provider about its return and exchange policies, and for information about hearing aid compatibility.

Hearing aid compatibility rating for this smartphone: M4/T4.

How the ratings work

M-Ratings: Wireless devices rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than wireless devices that are not labeled. M4 is the better or higher of the two ratings.

T-Ratings: Wireless devices rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated wireless devices. T4 is the better or higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from wireless devices.

For more information about the actions that the FCC has taken with regard to hearing aid compatibility with wireless devices and other steps that the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, visit www.fcc.gov/cgb/dro.

FCC ID: 2ACCJN042

General information

- **Internet address:** tclusa.com
- **Manufacturer:** TCL Communication Ltd.
- **Address:** 5/F, Building 22E, 22 Science Park East Avenue, Hong Kong Science Park, Shatin, NT, Hong Kong
- **Electronic labeling path:** Touch **Settings > System > Regulatory & safety** or press *#07# to find more information about labeling ⁽¹⁾, such as FCC ID.

On our website, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by email to ask any questions you may have.

Your phone is a transceiver that operates on GSM: B2/3/5/8 (1900/1800/850/900), UMTS: B2/4/5/8 (1900/1700/850/900), LTE: B66/4/5/13/2/12/46/48, and B3/7/20/28 and 5G: n5/n2/n66. mmWave: n261, n260.

⁽¹⁾ This may vary depending on country.

Protection against theft ⁽¹⁾

Your phone is identified by an IMEI (phone serial number) shown on the packaging label and in the phone's memory. We recommend that you note the number the first time you use your phone by entering *#06# and keep it in a safe place. It may be requested by the police or your carrier if your phone is stolen. This number allows your phone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your phone or specific carrier services.

TCL Communication Ltd. shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the carrier exclusively.

⁽¹⁾ Contact your service provider to check service availability.



Frequency Stability

The product meets Section 15.407(g) requirements from KDB 789033 D02v02r01. The emissions are maintained within the band of operation under all conditions of normal operation.

1 Your mobile

1.1 Keys and connectors







Back

- Tap once to return to the previous screen, or to close a dialog box, options menu, or notification panel.



Home

- From any application or screen, tap to return to the Home screen. Touch and hold to turn on Google Assistant, a program that provides detailed information based on the content detected on the screen.



Recent Apps

- Tap to view the applications you have open.



Power/Lock key

- Press: Lock the screen/Light up the screen.
- Press and hold: Show the pop-up menu to select from **Power off**, **Restart**, or **Airplane mode**.
- Press and hold the **Power** key and **Volume down** key at the same time to capture a screenshot.
- Press and hold the **Power** key for at least 9 seconds to force reboot.



Volume buttons

- In call mode, adjusts the earpiece or headset volume.
- In Music/Video/Streaming mode, adjusts the media volume.
- In general mode, adjusts the ringtone volume.
- Mutes the ringtone of an incoming call.
- In camera preview mode, press the **Volume up** or **down** key to take a photo or press and hold to take burst shots.
- Press Volume up and down keys at the same time for 3 seconds to start an accessibility feature when Volume keys shortcut is on. To set, touch **Settings > Accessibility > Volume keys shortcut**.

NOTE: Devices and software are constantly evolving – the screen images and icons you see here are for reference only.


1.2 Setting up your phone

Your phone already has a NANO SIM card installed. MicroSD cards (capacity up to 256GB) may be purchased separately.

Insert the SIM card*/microSD card


Power off the device before opening the SIM tray to remove and/ or insert the NANO SIM or microSD card.

Step 1. If you need to replace the NANO SIM card and/or insert an optional microSD card, use the SIM pin provided in the box to open the SIM tray.



Step 2. Remove the NANO SIM card/microSD card tray.

Step 3. Position the SIM card and/or microSD card in the tray correctly, aligning the cutout tab and gently snap into place. Be sure the edges are aligned.



Step 4. Slide the tray slowly into the SIM tray slot. It only fits one direction. Do not force into place. Keep the SIM tool in a safe place for future use.


NOTE: The microSD card is sold separately.

*A Subscriber Identity Module (SIM) card is a “smartcard” that houses personal information, such as your mobile number, calling plan and account information. The Verizon 5G UW SIM card is compatible with any Verizon 5G UW certified device that uses the same size SIM card. The 5G UW SIM card can move from one device to another, and your wireless service will support the services that are compatible with your new device and service plan. To see which devices are compatible with the Verizon 5G UW SIM card, visit [verizonwireless.com/certifieddevice](https://www.verizonwireless.com/certifieddevice)

Charge your phone

You might need to charge the battery before using your phone by inserting the small end of the charging cable into the charger port as shown.

Charge your phone fully before turning it on and starting the set up process. Insert the other end of the USB cable into your wall charger and plug it into a wall outlet.



WARNING: Only use the charger and cable supplied with the phone. Using incompatible chargers or tampering with the charging port could damage your device and void the warranty.

1.3 Home screen

The Home screen provides quick access to all the items (applications, shortcuts, folders and widgets) you like to use most frequently.

Touch the Home symbol to get instant access to the Home screen.

Notification Bar

- Status/Notification indicators
- Touch and drag down to open the notification panel

Search bar

- Touch ❶ to enter text search screen
- Touch ❷ to speak to Google Assistant.

Touch an icon to open an application, folder, etc.

Favorite applications tray

- Touch to enter the application
- Touch and hold to move or remove applications

Back | Home | Recent apps



Auto-rotate screen



The auto-rotate functions allows the screen to be displayed horizontally or vertically, depending on how you hold the phone. Automatically change the screen orientation from portrait to landscape by turning the phone sideways to have a better screen view.

From the Home screen, Swipe up to open the App drawer, then tap **Settings > Display > Auto-rotate screen** to enable or disable the function.

1.3.1 Using the touchscreen

Tap 

To access an application, tap it with your finger.

Touch & hold 

Touch and hold an item on the screen to open available options. For example, select a contact in Contacts, touch and hold this contact, and an option list will appear.

Drag



Touch and hold an item and drag it to another location.

Slide/Swipe



Touch and slide the screen to scroll up and down the applications, images, and web pages. You can slide the screen horizontally too.

Flick



Similar to swiping, flicking is a lighter and quicker stroke.

Multi-touch



Pinch or spread your thumb and index finger to zoom in or out.

The phone also supports one finger zooming in Photos. Double tap the screen to zoom in/out.

1.3.2 Status bar


From the Status bar, you can view both phone status and notification information.

Slide down the status bar to view notifications and slide down again to enter the Quick Settings Panel.

Swipe up to close it the Quick Settings Panel.

Notification panel

When there are notifications, slide down the **Status bar** to open the **Notification panel** to read more detailed information.




Touch to access **Settings**, where you can set more items.


Touch to clear all event-based notifications (other ongoing notifications will remain).

Quick Settings panel

Touch and drag down from the top of the screen once using two fingers, or twice using one finger to open the Quick settings panel.

You can enable or disable functions or change modes by touching the icons.

Touch the **Edit** icon  to customise your Quick settings panel.



Touch to turn on/off items, e.g. Wi-Fi, Bluetooth etc.

Touch to customise your Quick settings panel.

1.3.3 Locking and unlocking your screen

To protect your phone and privacy, you can lock the phone with a pattern, PIN, password or facial recognition.

Creating a screen lock/unlock setting

- From the Home screen, swipe up to open the App drawer, then tap **Settings > Security > Screen lock**.
- Choose your lock preference and follow the prompts.


To lock phone screen

Press the **Power/Lock** key once to lock the screen.

To unlock the phone screen

Press the **Power/Lock** key once to light up the screen. If applicable, draw the unlock pattern you have created, or enter your PIN or password.

If you have chosen **Swipe** as the screen lock, you can press the **Power/Lock** key to light up the screen, then swipe up to unlock the screen.



Enter a password to unlock the screen

Once the screen is turned on, swipe up from any position on the screen to display the password input panel. Then enter your lock screen password.

Use pattern unlock

Draw the same pattern you have set to unlock the screen.

Use Face unlock

From the app list, touch **Settings > Security > Face recognition**. Before using the face unlock, you need to set a pattern/PIN/password.

Hold your phone 8-12 inches from your face. Position your face in the square shown on the screen. For best results, we suggest that the face key is enrolled indoors and away from direct sunlight.

Enable Face unlock when screen turns on, or you have to swipe first before.

Use Fingerprint unlock

Touch the fingerprint sensor with an enrolled finger to unlock the screen.

1.3.4 Personalizing your Home screen

Add

You can touch and hold a folder, an application or a widget and drag the item to your preferred Home screen.

Reposition

Touch and hold an item, drag it to the desired position and then release. You can move items both on the Home screen and the Favorite applications tray. Hold the icon on the left or right edge of the screen to drag the item to another Home screen.

Remove

Touch and hold a folder, application, or widget, and drag it up to the top of the screen to **Remove** icon,

then release.

Create folders

To improve the organization of shortcuts or applications on the Home screen and the Favorite applications tray, you can add them to a folder by stacking one item on top of another. To rename a folder, open it and tap the folder's title bar to input the new name.

Wallpaper customization

Touch and hold an empty area on the Home screen, then tap **Wallpapers** to customize the wallpaper.


1.3.5 Widgets and recently used applications


Widgets

Touch and hold the empty area on the Home screen, then tap **Widgets** to display all widgets.

Move the selected widget by dragging it to your preferred screen.

Recently used applications

To review recently used applications, tap the **Recent Apps**  icon. Tap a thumbnail window to open the application to full screen.



Tap one thumbnail and swipe it up to close an application.

Slide right and touch **CLEAR ALL** to activate the system's one key boost which clears memory used by recent applications.

1.3.6 Adjusting the volume

Using the volume button

Press the **Volume** up or down key to adjust the Media volume.

Touch the \surd icon to open the window and display Alarm, Ring and Notification volume.



Using the settings menu

From the Home screen, Swipe up to open the App Drawer, then select **Settings > Sound** to set the volume for media, ring, alarm and more.

2 Text input.....


2.1 Using the on screen keyboard

Adjust the on screen keyboard orientation

Turn the phone sideways or upright to adjust the on screen keyboard orientation. You can adjust it by changing the settings. Go to **Settings > Display > Auto-rotate screen**

Onscreen keyboard settings

Other keyboards are available on your phone. Go to **Settings > System > Languages & input > Virtual keyboard**, select the keyboard you want to set up and a series of settings will become available.



- 1 Enter text or numbers.
- 2 Tap to attach media.
- 3 Tap to capitalize a letter. Touch and hold to CAPS Lock (to type in all capital letters) and tap again to turn off CAPS Lock.
- 4 Tap to switch to symbol and numeric keyboard.
- 5 Tap to insert a comma. Touch and hold to open keyboard settings.
- 6 Tap to open an emoji list.
- 7 Tap to insert a period. Touch and hold to select different punctuation symbols.

2.2 Text editing

You can edit the text you enter.

- Touch and hold or double tap within the text you want to edit.
- Drag the tabs to change the selected text.
- The following options will show: **Cut, Copy, Share** and **Select all**.

You can also insert new text if preferred


- Tap where you want to type, or touch and hold a blank space, the cursor will blink and a tab will show. Drag the tab to move the cursor.
- If you have cut or copied any text, tap the tab to show **Paste** which allows you to paste any text you have previously copied.


3 Call, Call log and Contacts

3.1 Call





3.1.1 Making a call



To make a call, tap  in the Favorite applications tray.





Long press to
access voicemail




Enter the desired number from the keypad and tap  to place the call or select a contact from **Contacts** or **Call Log** by sliding or tapping tabs and then make the call.

The number you entered can be saved to **Contacts** by tapping the **Create new contact** icon  or the **Add to a contact** icon .

If you make a mistake, you can delete the incorrect digits by tapping .


To hang up a call, tap .

International call


To dial an international call, touch and hold  to enter “+”, then enter the international country prefix

followed by the full phone number and tap .

Emergency call

If your phone has network coverage, dial the emergency number and tap  to make an emergency call. This works even without a SIM card and without typing the PIN code.




3.1.2 Answering or rejecting a call



When you receive a call, a call window will be presented on top of the screen. Touch **DECLINE** to dismiss a call or **ANSWER** to answer a call.

Touch the call window to open the Phone call screen.


On the Phone call screen:

- Swipe Phone  up to answer the call;
- Swipe Phone  down to reject the call;
- Swipe Message  up to reject the call by sending a preset message.
- To mute incoming calls, press the Volume Key.

3.1.3 Calling your voicemail

Your voicemail is provided by your network to avoid missing calls. It works like an answering machine that you can consult at any time.

To access your voicemail, touch and hold .


If you receive a voicemail,  appears on the Status bar. Open the Notification panel and tap **New voicemail**.

3.1.4 Setting up Voicemail

Follow the instructions provided by your mobile phone service provider.

3.1.5 During a call

To adjust the volume during a call, press the Volume button.



End the current call.



Tap once to activate the speaker during the current call. Tap this icon again to deactivate the speaker.



Tap to mute sound input and turn off the microphone on the phone (you will hear the caller, but the caller will not hear you). Tap this icon again to turn the microphone back on and unmute.



Display the keypad.



Tap to make a video call.



To avoid accidental operation of the touch-screen during a call, the screen will be locked automatically when you put the phone close to your ear; and it will be unlocked when the phone is taken away from your ear.

3.1.6 Managing multiple calls




This phone can handle multiple calls at once.

Swap calls

When you accept two calls, tap the contact name or number to switch between two lines. The current call will be put on hold and you will be able to join the other call.


Conference calls ⁽¹⁾

You can set up a conference call as follows.


- Place a call to the first participant of the conference call.
- Tap  and then tap Add call to add another call.
- Enter the phone number of the person you want to add to conference and tap . You can also add participants from Call log or Contacts.
- Tap  to merge the calls and start the confer-

⁽¹⁾ Number of calls is limited to 10 on the Verizon Network.

ence.


- Tap  to end the conference call and disconnect all callers.

3.1.7 Call settings

From the **Call** screen, tap  and then tap **Settings** to edit your phone settings, such as quick responses, accessibility and speed dial settings.

Tap any option and follow the instructions.

3.2 Call log

View a call log of missed, outgoing and incoming calls by tapping  on the **Call** screen.

Tap item to view information or further operations, you can launch a new call, send a message to the contact or number, view detailed information of the call, etc.

Touch one contact to view information or further operations. You can launch a new call, send a message to the contact or number, or view detailed information of the call.

To delete the call history of selected contact or number, long press the contact and choose **Delete**.

Tap  and select **Call history** to view all call log,  or **Clear all history** to clear the entire call memory.

3.3 Contacts.....




Contacts enables quick and easy access to the contact you want to reach.

You can view and create contacts on your phone and synchronize them with your Gmail contacts or other applications on the web or on your phone.

3.3.1 View your Contacts

To see your contacts, tap  from the App drawer.



Tap to delete selected contacts.

Tap to search contacts


Tap a contact to open the Quick Contact Panel. Touch and hold to select multiple contacts.


Add new contact



Deleted contacts will also be removed from other applications on the phone or web the next time you synchronize your phone.

3.3.2 Adding a contact


Tap  in the contact list to create a new contact. Enter the contact's name and other contact information.




Touch to save


Select a picture or take a photo for the Phone contact

Add/Remove from Favorites



To add a contact to favorites, you can tap a contact to view details then tap . The contact will now appear on your favorites list within the Phone application.


To remove a contact from favorites, tap the star  on the contact details screen.

3.3.3 Editing your contacts

To edit contact information, tap  in the contact details screen.

3.3.4 Use Quick Contact for Android


Tap a contact in your contacts list to open Quick Contact Information. You can then tap  or the number to make a call. To send a message, tap .




The icons available on the Quick Contact panel depend on the information you have for the contact and the applications and accounts on your phone.

3.3.5 Importing, exporting and sharing contacts

This phone enables you to import or export contacts between your phone, NANO SIM card and phone storage.


From the Contacts screen, tap  to open the options menu. To import/export contacts to/from NANO SIM Card, phone or microSD card storage, go to **Settings > Import/Export**.


You can share a single contact or several contacts by sharing the contact's vCard via Bluetooth, Gmail, etc.

Tap the contact you want to share, tap  and **Share** from the contact details screen. Select the application to perform this action.


3.3.6 Displaying contacts

You can configure which list of contacts, for each account, you want to display in the Contacts list.


From **Contacts** tap  > **Settings > Contacts to display** then you can choose which contacts to display.

You can also choose your display preference. From the **Contacts** list, tap  **Settings > Sort by** to sort the list by **First name** or **Last name**, as well as viewing contact names by **First name first** or **Last name first**.

3.3.7 Merging/Separating contacts


To avoid duplication, you can add any new contact information to existing contacts in a single action. Tap the contact which you want to add information to, touch  and touch **Link**.

Select the contact whose information you want to merge with the first contact. The information from the second contact is added to the first one, and the second contact will no longer be displayed in the **Contacts** list.

To separate contact information, tap the contact whose information you want to separate, then tap  and tap **View linked contacts**, tap **UNLINK** to confirm.

3.3.8 Synchronizing contacts in multiple accounts

Contacts, data or other information can be synchronized from multiple accounts, depending on the applications installed on your phone.

To add an account, tap  from the contacts list and tap **Settings > Accounts**, or from the Home screen, Swipe up the screen, then **Settings > Accounts > Add account**.

Select the type of account you are adding; for example, personal, corporate, Google or cloud.

As with other account setups, you need to enter de-

tailed information, such as username and password. You can remove an account to delete it and all associated information from the phone. Tap the account you want to delete, then tap **Remove Account** to remove it.

Auto-sync


On the **Accounts** screen, turn on/off the **Automatically sync data** to activate/deactivate this function. When activated, all changes to information on the phone or online will be automatically synchronized.


4 Messaging




4.1 Write a new message

You can create, edit, send and receive SMS and MMS with this phone.

To access Messaging, tap .

On the message list screen, tap  to create text/multimedia messages.



Choose contacts

Insert emojis

Send the text message

Sending a text message

To add recipients, enter the name or phone number of the recipient in the **To** bar. Tap the **Type message** bar to enter the text of the message. When

finished, tap ➤ to send the text message. Specific letters (accented) will also increase the size of the SMS.

Sending a multimedia message

MMS enables you to send video clips, images, photos, animations, and sounds to other compatible mobiles and email addresses.


An SMS will be converted to MMS automatically when media files (image, video, audio) are attached or email addresses are added.

To send a multimedia message, enter the recipient's phone number in the **To** bar. Tap the **Type message** bar to enter the text of the message.

Tap + to attach a picture, video or audio file.

When finished, tap ➤ to send the multimedia message.


4.2 Manage messages



When receiving a message,  will appear on the Status bar as a notification. Drag down the Status bar to open the Notification panel. Tap the new message to open and read it. You can also access the Messaging application and tap the message to open it.

Messages are displayed as a conversation.

Tap a message to enter the message composing

screen:



- Tap  to call the number. To adjust message settings, tap  and select **Settings** on the message list screen.

5 Calendar and Clock.....

5.1 Calendar.....



You can use **Calendar** to keep track of important meetings, appointments, etc.


To view the calendar and create events, Swipe up from the Home screen, then tap **Calendar**.

5.1.1 Multimode view


You can display the Calendar by **Schedule, Day, 3 days, Week,** or **Month**, tap  to change your view.

5.1.2 To create new events



You can add new events from any Calendar view.

- Tap .
- Fill in all required information for this new event. If it is a whole-day event, you can select **All-day**.
- To add invitees to an event, enter email addresses separated by commas. Invitees will receive a calendar invitation by email.
- When finished, tap Save from the top of the screen.


To quickly create an event from the Week view

screens, tap an empty spot to select a target area which will then turn , then tap the icon to create the new event.

5.1.3 To delete or edit an event

To delete or edit an event, tap the event to enter the details screen. Tap  to edit the event, or tap  and then **Delete** to delete.

5.1.4 Event reminder

If a reminder is set for an event, the upcoming event icon  will appear on the Status bar as a notification when the reminder time arrives.


Touch, hold and drag down the Status bar to open the Notification panel and tap an event name to view the Calendar notification list.

Tap the **Back** button to keep the reminders pending in the Status bar and the Notification panel.

5.2 Clock







Your mobile phone has a built-in clock.

To view the current time, touch  from the app drawer.

5.2.1 Alarm

From the Clock screen, touch **Alarm** to enter.

- Turn on  to enable the alarm.
- Touch  to add a new alarm, touch  to save.
- Touch a currently existing alarm to enter the alarm editing screen.
- Touch  to delete the selected alarm.



5.2.2 Clock




To view the date and time, touch **Clock**.

After pressing clock icon , then pressing +, select city where you live. Add other cities if needed. Then select other clock functions.

5.2.3 Timer


From the Clock screen, touch **Timer** to enter.








- Set the time.
- Touch  to start the countdown.
- Touch  to pause.
- Touch  to reset.

5.2.4 Stopwatch

From the Clock screen, touch **Stopwatch** to enter.



- Touch  to start the Stopwatch.
- Touch  to show a list of records according to the updated time.
- Touch  to pause.
- Touch  to reset.
- Touch  to share.

5.2.5 Adjust Clock settings

Tap  to access **Clock**, **Alarms** and **Timers** settings.

6 Getting connected

To connect to the internet with this phone, you can use the network or Wi-Fi, whichever is most convenient.

6.1 Connecting to the internet

6.1.1 Network connection

The first time you turn on your phone with your SIM card inserted, the phone will begin a setup wizard. If the phone is not connected to the network, you may connect to a Wi-Fi network. In the phone menu, tap **Settings > Network & internet > Wi-Fi**.

To check the network connection you are using, tap **Settings > Network & internet > Mobile network > Network**.


To enable data roaming

- Tap **Settings > Network & internet > Mobile network > Roaming**.
- When data roaming is disabled, you can still perform data exchange with a Wi-Fi connection (refer to "**6.1.2 Wi-Fi**").

6.1.2 Wi-Fi

You can connect to the internet when your phone is within range of a wireless network. Wi-Fi can be used on your phone even without a SIM card inserted.

To turn Wi-Fi on and connect to a wireless network

- Tap **Settings > Network & internet > Wi-Fi**.
- Turn on .
- Once Wi-Fi is turned on, detected Wi-Fi networks are listed.
- Tap a Wi-Fi network to connect to it. If the network you selected is secured, you are required to enter a password or other credentials (you may contact the network operator for details). When finished, tap **CONNECT**.

To add a Wi-Fi network

When Wi-Fi is on, you may add new Wi-Fi networks according to your preference.

- Tap **Settings > Network & internet > Wi-Fi > Add network**.
- Enter the name of the network and any required network information.
- Tap **SAVE**.

To forget a Wi-Fi network


The following steps prevent automatic connections to networks which you no longer wish to use.

- Turn on Wi-Fi, if it's not already on.
- On the Wi-Fi screen, tap Saved networks.
- Tap the name of the saved network and tap **FORGET** in the dialog that opens.

6.2 Connecting to a Bluetooth device

Bluetooth is a short-range wireless communication technology that you can use to exchange data, or connect to other Bluetooth devices for various uses.

To turn on Bluetooth

- Tap **Settings > Bluetooth & device connection > Bluetooth**.
- Turn on .
- Tap + **Pair new device**.

Your device name and other available devices will appear on screen.

To rename your device


- Tap **Bluetooth & device connection > Bluetooth**.
- Tap **Device name**.
- Enter a name, and tap **RENAME** to confirm.

To pair/connect your phone with a Bluetooth device

To exchange data with another device, you need to turn Bluetooth on and pair your phone with the Bluetooth device with which you want to exchange data.

- Tap **Bluetooth & device connection > Bluetooth**.
- Tap + **Pair new device**.
- Tap a Bluetooth device you want to pair your phone with in the list.
- In the dialog that pops up, tap **PAIR** to confirm.
- If the pairing is successful, your phone will be connected to the device.

To disconnect/unpair from a Bluetooth device

- Tap  beside the device you want to unpair.
- Tap **FORGET** to confirm.

6.3 Connecting to a computer via USB

With a USB cable, you can transfer media files and other files between your phone and a computer.

To connect your phone to the computer

Use the USB cable that came with your phone to connect the phone to a USB port on your computer. You will receive a notification that the USB is connected.

Everytime you connect the phone via USB, a dialogue box pops up, tap **ALLOW** to allow data exchange between your phone and computer, or tap **DENY** to use USB for charging only.

When you tap **ALLOW**, open the Notification panel and tap **USB file transfer turned on**, choose the way in which you want to transfer files. By default, **MTP mode** is selected.

You can also tap **Other USB options** directly to choose the way in which you want to transfer files.



Before transferring media to a computer, ensure the phone and computer have the most up-to-date version of media player installed.

6.4 Sharing a mobile data connection

You can share your phone's mobile data connection with a single computer via a USB cable (USB tethering), with Bluetooth (Bluetooth tethering) or via Wi-Fi (mobile hotspot).



The functions below may incur additional network charges from your network operator. Extra fees may also be charged in roaming areas.

To share your phone's data connection via USB and Bluetooth, or as a Wi-Fi hotspot

Go to **Settings > Network & internet > Hotspot & tethering** to activate these functions.

To rename or secure your mobile hotspot

When mobile hotspot is activated, you can rename your phone's Wi-Fi network (SSID) and secure it.

- Tap **Settings > Network & internet > Hotspot & tethering > Mobile Hotspot**.
- Tap **Set up Mobile Hotspot** to rename the network SSID or set your network security.
- Tap **SAVE**.

6.5 Connecting to virtual private networks

Virtual private networks (VPNs) allow you to connect to the resources inside a secured local network from outside that network. VPNs are commonly deployed by corporations, schools, and other institutions so that their users can access local network resources when not inside that network, or when connected to a wireless network.

To add a VPN

- Tap **Settings > Network & internet > VPN** and then tap **+**.
- On the screen that opens, follow your network administrator's instructions to configure each component of the VPN settings.
- Tap **SAVE**.

The VPN is added to the list on the VPN settings screen.

To connect/disconnect to/from VPN

To connect to a VPN:


- Tap **Settings > Network & internet > VPN**.
- The VPNs you have added are listed. Tap the VPN you want to connect with.
- In the dialog that opens, enter any requested credentials and tap **CONNECT**.

To disconnect from a VPN:


- Tap the VPN you want to disconnect from. In the dialog that opens, tap **DISCONNECT**.

To edit/delete a VPN

To edit a VPN:

- Tap **Settings > Network & internet > VPN**.
- The VPNs you have added are listed. Tap the  icon next to the VPN you want to edit.
- After editing, tap **SAVE**.

To delete a VPN:

- Tap the  icon next to the selected VPN, then tap **FORGET** to delete it.


7 Multimedia applications .


7.1 Camera





Your mobile phone is fitted with a camera for taking photos and videos.

Before using the camera, make sure that you remove the protective lens cover to avoid it affecting your picture quality.



To take a photo or video, touch  from the app drawer.






To take a photo


The screen acts as the viewfinder. First, position the object or landscape within the viewfinder, tap the screen to adjust the image focus to a specific point or object, and tap the Capture button  or press the **Volume key** to take a photo. The photo will be automatically saved. You can also touch and hold  to take burst shots.

To take a video

Swipe to the right on the **Camera Mode** to enter **Video Mode**, then tap the **Record Button**  to start video recording. You can also tap the **Camera Shutter** icon  to take a picture during video recording.

Tap  to pause video recording and tap again  to continue. Tap  to stop recording. The video will be automatically saved.


Further operations when viewing a picture/video you have taken

- Slide left or right to view the photos or videos you have taken.
- Tap , then Gmail/Bluetooth/MMS/etc. to share the photo or video.

7.1.1 Modes and settings

Modes

Slide left or right to switch between modes.

- **More:** By selecting More, you can access more modes. These modes could be moved to the main screen by touching .

Slo-Mo: Record special occasions and fast moving scenes even in a dark environment, then play them back at a slow frame rate.

Stop motion: Capture a number of photos in a certain scene, then convert them into a speed up video.

Light trace: Capture creative movements of light using a long exposure photograph.

Pano: Touch to turn on the panorama function. Touch the shutter button to start taking a panoramic photo and move the phone steadily along the direction indicated by the onscreen line. Once the slots are filled, the photo will be automatically saved. If the slots are not fully filled, touch the shutter button again to save the photo.

Super macro: Touch to access super macro mode. 1 to 6 inches is the best macro shooting distance.


High Pixel: When capturing pictures the device

will only use the 48MP rear Camera.


- **Auto:** Auto is the default mode for Camera.
- **Video:** Touch to access video mode.
- **Portrait:** Touch to create a depth of field effect. You can compose an image that highlights your subject while producing a gorgeously blurred background.
- **Super Night:** This mode helps to capture wonderful pictures at night with low light.
- **Pro:** Pro camera mode lets you fine-tune parameters and gives you full control over ISO, WB exposure time, aperture, shutter speed and so on.

Settings


Touch  to set more options:

- **Photo size:** Touch to select quality (Higher number of MP).
- **Video quality:** Touch to select video quality.
- **Video stabilisation (EIS):** Touch to turn on/off.
- **AI scene detection:** Touch to turn on/off AI noise reducing function and AI anti-shaking with Neural network learning solution.
- **Calorie detection⁽¹⁾:** Turn on  to detect the calorie content of a captured object.

⁽¹⁾ Only available when the AI camera is turned on.

- **Smart guideline⁽¹⁾:** Touch to turn on/off.
- **Dark shot:** Toggle the switch to take a wonderful picture in dark environment.
- **Volume button function:** Touch to customise the Volume button to Shutter, Zoom or Volume when using camera.
- **Touch to capture:** Touch to turn on/off. Once turned on, the image will be captured by simply touching the viewfinder screen.
- **Grid:** Touch to turn on/off. It divides the screen into equal parts and helps you take better photos by making it simple to align elements such as the horizon or buildings, to the lines in the grid.
- **Storage:** Touch to choose between phone and SD card storage when an SD card is inserted. The default is phone storage.
- **Save location information:** Turn on  to tag photos and videos with your location. This option is available when the GPS location service is enabled.
- **Shutter sound:** Touch to turn on/off shutter sound when capturing.
- **Reset settings:** Touch to reset the camera to its factory default settings.

Two more options are available when you switch to using the front camera:


- **Face beauty:** Touch  to adjust skin smoothing and enhance colouring effect to portraits.
- **Mirror camera:** Touch to turn on/off.

7.2 Viewing Photos or Videos.....




Google Photos acts as a media player to view, organize, share, and edit all your photos and videos.

To view the photos you have taken, swipe up from the Home screen to access the App Drawer and select **Google Photos**.



Album view in Google Photos




Full-screen picture view


Pictures and videos are displayed by **albums** in Google Photos.


Working with pictures

You can work with pictures by rotating or cropping them, sharing them with friends, and setting them as a contact photo or wallpaper.


Find the picture you want to work on, and tap the picture to enter the full-screen picture view.

Tap  to **Share** the picture via messaging, Gmail, and more.

Tap  to **Edit** the picture. You can add a **filter**, adjust the **picture color**, and **crop, straighten** or **rotate** the picture.

Tap  for **Information** on the date, location the photo was taken, MB size and camera settings.

Tap  to **Delete** the picture.

Tap  to **Print** or set the picture as a **contact photo** or **wallpaper**.

While in album view, touch and hold a picture for additional features and options in Google Photos.

8

Others.....

8.1 Other applications ⁽¹⁾

The previous applications in this section are pre-installed on your phone. To download and install more 3rd party applications, use the Google Play Store application.

⁽¹⁾ Application availability depends on country and operator.

9 Google applications

Google apps are preinstalled on your phone to improve work efficiency and help you enjoy life.

This manual briefly introduces the apps. For detailed features and user guides, refer to related websites or the introduction provided in the apps.

We recommend you register with a Google account to enjoy all the functions.

9.1 Chrome

A web browser with which you can surf the internet. Your bookmarks, browsing history, and settings across all devices with the browser installed can be synchronized with your Google account.

9.2 Gmail

As Google's web-based email service. With this application, you can send and receive emails, manage emails by labels, archive emails, etc. Emails can be automatically synchronized with your Gmail account.

9.3 Maps

Google Maps offers satellite imagery, street maps, 360° panoramic views of streets, real-time traffic conditions, and route planning for traveling by foot, car, or public transportation. By using this application, you can get your own location, search for a place, and get suggested route planning for your trips.

9.4 YouTube

YouTube is an online video-sharing application which allows users to upload, view, and share videos. Available content includes video clips, TV clips, music videos, and other content such as video blogging, short original videos, and educational videos. It supports a streaming function that allows you to start watching videos almost as soon as they begin downloading from the internet.

9.5 Drive

A file storage and synchronisation service created by Google, which allows users to store files in the cloud, share and edit files.

Files in Drive are kept secure and can be accessed from any device by logging in to your Google ac-

count. Files or folders can be shared privately with other Google account users.

9.6 Play Store

Serves as the official app store for the Android operating system, allowing users to browse and download applications and games. Applications are either free of charge or at a cost.

In Play Store, search for the app you need, download it and then follow the installation guide to install the app. You can also uninstall, update an app, and manage your downloads.

9.7 YouTube Music

YouTube Music is a music streaming service developed by YouTube, and a subsidiary of Google. You can play music files stored on your device or create an account to explore more music.

You can download and listen to a large number of songs for a monthly fee. In addition to offering music streaming for internet-connected devices, the YouTube Music app allows music to be stored and listened to offline. Songs purchased through the YouTube Music app are automatically added to the user's account.

9.8 Play Movies & TV



With Google Play Movies & TV you can rent or purchase on demand videos and TV shows to watch instantly on your phone. All purchases can also be downloaded to your phone to watch without streaming.

9.9 Duo

A video chat mobile app.

With phone numbers verified, users can easily video call people from their contact list.

10 Settings

Open Settings from the App Drawer by swiping up from the Home Screen and tapping the Settings  Icon, or swipe down from the Notification Bar and tapping the Settings Icon .

10.1 Network & internet

10.1.1 Wi-Fi

Using Wi-Fi you can access the internet without using your network data or NANO SIM card whenever you are in range of a wireless network. The only thing you have to do is to enter the **Wi-Fi** screen and configure an access point to connect your phone to the wireless network.

For detailed instructions on using Wi-Fi, refer to "**6.1.2 Wi-Fi**".

10.1.2 Wi-Fi Calling

Wi-Fi Calling allows your device to make a voice or video call over a Wi-Fi network.

10.1.3 Mobile network

You can set **Roaming**, **Enhanced 4G LTE Mode**, **Network Mode**, **Access Point Names** and etc in this menu.

10.1.4 Data usage

Data saver

By enabling **Data saver**, you can reduce data usage by preventing some apps from sending or receiving data in the background.

Mobile data

If you do not need to transmit data on mobile networks, turn off **Mobile data** to avoid incurring significant charges for data use on local operator mobile networks, particularly if you do not have a mobile data agreement.



Data usage is measured by your phone, and your operator may count differently.


10.1.5 Hotspot & tethering

This function allows you to share your phone's mobile data connection via USB and Bluetooth, or as a portable Wi-Fi hotspot (refer to "**6.4 Sharing a mobile data connection**").

10.1.6 VPN

For more information on VPN, refer to "**6.5 Connecting to virtual private networks**".

10.1.7 Airplane mode

Turn on **Airplane mode**  to simultaneously disable all wireless connections including Wi-Fi, Bluetooth and more.

10.1.8 Private DNS

Tap to select private DNS mode.

10.1.9 Wireless Emergency Alerts

Tap to enter wireless emergency alert settings, including whether to show threats and alert tones.

10.2 Bluetooth & device connection

10.2.1 Bluetooth

Bluetooth allows your phone to exchange data (videos, images, music, etc.) within a small range with another Bluetooth supported device (phone, computer, printer, headset, car kit, etc.).

For more information on Bluetooth, refer to “6.2 Connecting to a Bluetooth device”.

10.2.2 NFC

Turn on  to enable NFC.

The function allows data exchange when the phone touches another device.

10.2.3 Cast

You can use Cast to display your device's screen on your TV, and display content like TV shows, movies, photos, games, and websites from supported apps.

10.2.4 USB

You can use USB to charge this device, Supply power, Transfer files or transfer photos (PTP).

10.2.5 Printing

Touch Printing to activate print services. You can select your **Default print service** or choose **Add service** to select another service.

10.3 Display

10.3.1 Status bar

With this menu, you can set the style of the status bar, select whether notification icons are folded, show network speed and how the battery percentage is displayed.

10.3.2 Brightness level

Adjust screen brightness manually.

10.3.3 Dark mode

Your screen will become black in this mode, which makes it easier to look at your screen or read in dim light.

10.3.4 Eye comfort mode

Eye comfort mode can effectively reduce blue light radiation and adjust the colour temperature to relieve eye fatigue. You can also create a custom schedule to turn on it.

10.3.5 Adaptive brightness

Adjust screen brightness automatically.

10.3.6 Auto-rotate screen

Select whether the screen rotates automatically or not.

10.3.7 Sleep

Set screen timeout.

10.3.8 Font size

Set font size for the screen display.

10.4 NXTVISION

10.4.1 Visual enhancement

Toggle the switch to enable. Automatically adjust contrast, sharpness and saturation to make the screen image clearer, with a richer depth of detail and improved brightness for dark scenes when viewing photos or playing videos and games. Only works in 'Vivid' Screen colour mode.

10.4.2 SDR to HDR

This is only available after enabling visual enhancement.

Enhance the colour, contrast and depth of detail of streaming video from any source to provide HDR-quality viewing.

10.4.3 Reading mode

Reading mode reproduces a physical book reading experience on your screen. You can set individual apps to use this mode by clicking Manage apps menu.

10.4.4 Screen color

The device allows you to change the range of display tones according to the display content. When choosing Vivid, you can adapt the screen's colour temperature according to the ambient light.

10.4.5 Sunlight display

Toggle the switch to increase readability under sunlight.

10.5 Home screen & wallpapers

With this menu, set your home apps, choose your favourite wallpapers, theme styles, and etc.

10.6 Sound

Use the Sound settings to configure many aspects of call ringtones, music, and other audio settings.

10.6.1 Do Not Disturb preferences

If you do not want to be disturbed by your phone or information ringtones during work or rest, you can set the Do Not Disturb mode.

Swipe down the Status bar twice to access the Quick Settings panel and tap to turn on **Do Not Disturb**.

10.6.2 Phone ringtone

Touch to set your incoming call ringtone.

10.6.3 Default notification ringtone

Set the default sound for notifications.

10.6.4 Default alarm ringtone

Set your alarm ringtone.

10.6.5 Other sounds and vibrates

Set dial pad tones, screen locking sounds, touch-

sounds, etc.

10.7 Advanced features

10.7.1 System navigation

Select your favourite navigation button layout.

10.7.2 Gestures

To set some gestures for convenient use, such as flip to mute and Power key shortcut.

10.8 Smart Manager

Smart Manager ensures your phone is operating in top form by automatically scanning and optimising data usage to preserve battery levels, manage storage and protect against security threats.

Restricting auto-start apps can make the system run faster and extend battery life.

You can also do some manual settings for further optimisation.

10.9 Security

10.9.1 Screen lock

Select one method such as Swipe, Pattern, PIN, Password, or Fingerprint to unlock the screen.

10.9.2 Fingerprint sensor

Use your Fingerprint to unlock the screen or clear notifications, take a photo/video, pick up a call, and etc.

10.9.3 Face unlock

Face key allows you to unlock your device with your facial data. Set it according to the on-screen steps. Ensure that you are facing the phone screen when using face recognition.

NOTE: you need to set a pattern, PIN, or password before using face key.

10.9.4 Smart Lock

Smart Lock keeps your device unlocked when it's safe with you and locked when it detects that it's been put down.

10.9.5 Others

You can also set SIM card lock, Screen pinning, and etc.

10.10 Location

Tap to set whether to allow an app to access your device's location. You can set allowing all the time, or only while the app is in use.

10.11 Privacy

To protect your privacy, you can set an app to be allowed or forbidden to access your location, SMS, phone, etc. Also whether or not to show passwords or choose the activities and info that you want to Google to save.

10.12 Apps

Touch to view details about the applications installed on your phone, manage their data usage, force them to stop, set screen time, set timers for your apps and etc.

10.13 Storage

Use these settings to monitor the total and available space on your phone.

10.14 Account

Touch to add, remove, and manage your email and other supported accounts. You can also use these settings to control how and whether all applications send, receive, and synchronise data according to their own schedules, and whether all applications can synchronise user data automatically.

Touch **Add account** to add an account for the selected app.

10.15 Digital Wellbeing & parental controls

In this menu you can find how much time you have spent on the phone and even on each app. You can customise a time limit for using the phone.

In addition, parents are able to restrict their children's usage to manage their screen time.

10.16 Google

Touch to configure your Google account and services settings.

10.17 Accessibility

Use the Accessibility settings to configure any accessibility plug-ins you have installed on your phone.

10.18 System updates

Tap to check for system updates.

10.19 System

10.19.1 About phone

View basic information for your phone such as model name, CPU, camera, resolution, and etc.

You can also check legal information, build number, status and other specs.


10.19.2 Languages & input

Tap to configure language settings, the onscreen keyboard, voice input settings, pointer speed, etc.

10.19.3 Date & time

Use Date & time settings to customise your preferences for how date and time are displayed.

10.19.4 Backup

Turn on  to back up your phone's settings and other application data to Google servers. If you replace your phone, the settings and data you've backed up will be restored onto the new phone when you sign in with your Google account. If you mark this option, a wide variety of settings and data are backed up, including your Wi-Fi passwords, bookmarks, a list of the applications you've installed, the words you've added to the dictionary used by the onscreen keyboard, and most of the settings that you configure in the Settings application. If you unmark this option, you stop backing up your settings, and any existing backups are deleted from Google servers.

10.19.5 Reset

Touch to choose **Network settings reset** (including Wi-Fi, Mobile data & Bluetooth), **Reset app preferences**, **Factory data reset** or **Reset settings**.



Factory data reset will erase all of your personal data from the internal phone storage, including information about your Google account, any other accounts, your system and application settings, and any downloaded applications. We recommend you back up your personal data before resetting.

10.19.6 Regulatory & safety

Touch to view product information such as Product model, Manufacturer name, Manufacturer address, IMEI, CU reference, Bluetooth Declaration ID, and etc.

11 Making the most of your phone.....

11.1 FOTA Upgrade

Use the FOTA (Firmware Over The Air) Upgrade tool to update your phone's software. To access **System updates**, Swipe up the Home screen and select **Settings > System updates**.

If you want to update the system, tap **Check for new system update** and when that's finished, your phone will have the latest version of the software. Turn on data connection or Wi-Fi before searching for updates.

To avoid errors in locating the correct update packages, do not change your default storage location during FOTA downloading or updating.

12 Accessories.....

Standard accessories

1. Wall Charger
2. Type-C USB Cable
3. Quick reference guide
4. Product safety & warranty information
5. Important consumer safety information
6. SIM Tray Ejector Pin
7. Wrapped phone protective film
8. 5G Special Nano SIM Card sim card



- Accessories depend on countries.
- Only use the TCL accessories included with your device.

13 1 YEAR LIMITED WARRANTY

For information on warranty of your device, visit the USA and Canada websites at <https://support.tcl.com/us-mobile-product-downloads/614427>.



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

Electronic Information

For more information on Electronic Recycling:

- 1) Visit TCL Electronic Recycling Program website at <https://www.tcl.com/us/en/mobile/accessibility-compliance/tcl-mobile-electronic-recycling-program.html> / or
- 2) Call TCL US Customer Support at 1-855-224-4228.

TCL Communication Technology Holdings Limited. reserves the right to alter material or technical specification without prior notice. TCL is a registered trademark of TCL Technology Group Corporation © 2020 TCL Technology Group Corporation.

14 Troubleshooting.....

Before contacting the service centre, here are some instructions to help you troubleshoot your device:

- For optimal operation, fully charge the battery.
- To improve the phone's performance, remove unnecessary files or apps on your phone.
- Update your phone's software via **Settings > System updates**.
- Reset your phone via **Settings > System > Reset > Factory data reset**. Another method is to hold down the **Power** key and the **Volume up** key at the same time when your phone is powered off. Select **Wipe data / factory reset > Factory data reset > Reboot system now** to reset. All your phone data will be lost permanently. It is strongly advised to fully back up your phone data before resetting.

and carry out the following checks:

My phone can't be switched on or is frozen

- When the phone can't be switched on, charge for at least 20 minutes to ensure the minimum battery power needed. Then switch it on again.
- When the phone falls into a loop during power on animation and the user interface can't be

accessed, press and hold the **Power** key to reset. This eliminates any abnormal OS booting issues caused by third party applications.

- If neither method is effective, reset the phone by pressing the **Power** key and the **Volume up** key at the same time, then select **Wipe data / factory reset > Factory data reset > Reboot system now** to reset.

My phone has not responded for several minutes

- If your phone doesn't respond, turn off your phone by pressing and holding the **Power** key until it turns off and then restart it again.
- If it still doesn't work, reset the phone.

My phone turns off by itself

- Check that your screen is locked when you are not using your phone, and make sure that the **Power** key is not accidentally pressed while the screen is unlocked.
- Check the battery charge level.
- If it still doesn't work, reset the phone or update software.

My phone can't charge properly

- Make sure that you are using the TCL charger that comes with the phone.
- Make sure that your battery is not completely

discharged; if the battery power has been empty for a long time, it may take around 20 minutes to display the battery charging indicator on the screen.

- Make sure that charging is carried out under normal conditions 0°C (32°F) to 40°C (104°F).
- When abroad, check that the voltage input is compatible.

My phone can't connect to a network or "No service" is displayed

- Try connecting to the network by moving to another physical location.
- Verify the network coverage with your operator.
- Check with your operator that your SIM card is valid.
- Try connecting at a later time if the network is overloaded.


My phone can't connect to the internet

- Make sure that the internet access service of your SIM card is available.
- Check your phone's internet connection settings.
- Make sure that you are in a place with network coverage.
- Try connecting at a later time or another location.

Invalid SIM card

- Make sure that the SIM card has been correctly inserted.
- Make sure that the chip on your SIM card is not damaged.
- Make sure that the service of your SIM card is available.

My phone can't make outgoing calls

- Make sure that you have dialed a valid number and have touched .
- For international calls, check the country and area codes.
- Make sure that your phone is connected to a network, and the network is not overloaded or unavailable.
- Check your subscription status with your operator (credit, SIM card valid, etc.).
- Make sure that you have not barred outgoing calls.
- Make sure that your phone is not in aeroplane mode.

My phone can't receive incoming calls

- Make sure that your phone is switched on and connected to a network (check for overloaded or unavailable network).

- Check your subscription status with your operator (credit, SIM card valid, etc.).
- Make sure that you have not forwarded incoming calls.
- Make sure that you have not barred certain calls.
- Make sure that your phone is not in aeroplane mode.

The caller's name/number doesn't appear when a call is received

- Check that you have subscribed to this service with your operator.
- Your caller may have concealed his name or number.

I can't find my contacts

- Make sure that your SIM card is not broken.
- Make sure that your SIM card is inserted properly.

The sound quality of the calls is poor

- Adjust the volume during a call by pressing the **Volume** key.
- Check the network strength. Move to a location with stronger signal strength.
- Make sure that the receiver, connector and speaker on your phone are clean.

I can't use the features described in the manual

- Check with your operator to make sure that your subscription includes this service.
- Make sure that this feature doesn't require a TCL accessory.

When I select a number from my contacts, the number can't be dialed

- Make sure that you have correctly recorded the number in your contacts.
- Make sure that you have selected the country code when calling an international number.

I can't add a contact

- Make sure that your SIM card contacts are not full; delete some contacts or save the contacts to the phone.

My callers can't leave messages on my voicemail

- Contact your network operator to check service availability.

I can't access my voicemail

- Make sure that your operator's voicemail number is correctly entered in "Voicemail number".
- Try later if the network is busy.

I can't send and receive MMS

- Check your phone storage as it might be full.

- Contact your network operator to check service availability and MMS parameters.
- Verify the server centre number or your MMS profile with your operator.
- The server centre may be swamped. Try again later.

SIM card PIN locked

- Contact your network operator to obtain the PUK (Personal Unblocking Key) code.

I can't connect my phone to my computer

- Check to make sure the USB port is not broken. If it's not working, try another USB port on your computer.
- Make sure USB drivers are properly installed.
- If you are using a Windows computer, make sure it supports MTP mode. If you are using a Mac, make sure to install Android File Transfer from www.android.com/filetransfer/.

I can't download new files

- Make sure that there is sufficient phone storage space for your download.
- Select the microSD card as the location to store downloaded files.
- Check your subscription status with your operator.

The phone can't be detected by others via Bluetooth

- Make sure that Bluetooth is turned on and your phone is visible to other users.
- Make sure that the two phones are within Bluetooth's detection range.

The battery drains too fast

- Make sure that you follow the complete charge time (minimum 120 minutes).
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication.
- Adjust the brightness of screen as appropriate.
- Extend the email auto-check interval for as long as possible.
- Update news and weather information on manual demand, or increase their auto-check interval.
- Exit background-running applications if they are not being used for extended periods of time.
- Turn off Bluetooth, Wi-Fi, or GPS when not in use.

The phone becomes warm following prolonged calls, game playing, internet surfing or running other complex applications

- This heating is a normal consequence of the CPU handling a large amount of data. Ending

the above actions will make your phone return to normal temperature.

After a factory data reset is performed, I can't use my phone without entering Google account credentials

- After a reset is performed, you must enter the original Google account credentials that were used on this phone.
- If you don't remember your Google account credentials, complete Google account recovery procedures.
- If you still cannot access your phone, apply to the authorised repair centre, but remember that it will not be regarded as a warranty case.

I forgot some passwords/codes/keys on phone

- Perform a factory data reset.
- If you still cannot access your phone, apply to the authorised repair centre, but remember that it will not be regarded as a warranty case.

15 Specifications.....

Processor:

- Qualcomm Snapdragon 765G

Platform:

- Android 10

Memory:

- 128GB ROM + 6GB RAM

Dimensions (LxWxT):

- 6.44" x 3" x .37"

Weight:

- 7.4"

Display:

- 6.53" touch screen with 2340x1080

Network:

- GSM: B2/3/5/8 (1900/1800/850/900)
- UMTS: B2/4/5/8 (1900/1700/850/900)
- LTE: B66/B4/B5/B13/B2/B12/B46/B48, and B3/7/20/28
- 5G: n5/n2/n66 and mmWave: n261, n260

GPS:

- A-GPS

Connectivity:

- Bluetooth 5.0
- Wi-Fi 802.11 b/g/n for 2.4GHz, 802.11 a/n/ac for 5GHz
- 3.5 mm audio jack
- Type-C USB 3.1

Camera:

- 48MP+8Mp super wide+5Mp Macro
- 16MP front camera

Audio & Video supported formats:

- AAC LC, AAC+, eAAC+, AAC ELD, AMR-NB, AMR-WB, FLAC, MIDI, MP3, Opus, WAV, Vorbis, ALAC, AIFF, APE
- (decoder) H.264, MPEG-2, VP8, VP9(8-bit and 10 bit), MPEG-4, H.263, (encoder) H.264, VP8, MPEG-4, H.263

Battery (1):

- Capacity: 4500 mAh

Expansion Slot:

- microSD™ memory card
(Availability of microSD card depends on market)

(1) The original battery has undergone rigorous safety inspections to meet qualification standards. The battery is not removable from the phone and doing so will void the warranty. Phone may be serviced only by an authorized TCL service center..

Special Features:

- GPS/GLONASS/Galileo/Beidou/QZSS
- G-sensor
- Light Sensor
- Proximity Sensor
- E-Compass
- Gyro

Note: Specifications are subject to change without prior notice.

English - CJA67H001AAA